



Maintenance and Service Guide

SUMMARY

This guide provides information about spare parts, removal and replacement of parts, security, backing up, and more.

© Copyright 2020 HP Development Company, L.P.

AMD and Radeon are trademarks of Advanced Micro Devices, Inc. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Intel, Celeron, Core, Optane, Pentium, Thunderbolt, and vPro are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. USB Type-C and USB-C are registered trademarks of USB Implementers Forum. DisplayPort and the DisplayPort logo are trademarks owned by the Video Electronics Standards Association (VESA) in the United States and other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: August 2020

Document Part Number: M05546-001

Product notice

This guide describes features that are common to most models. Some features may not be available on your computer.

Not all features are available in all editions or versions of Windows. Systems may require upgraded and/or separately purchased hardware, drivers, software or BIOS update to take full advantage of Windows functionality. Windows 10 is automatically updated, which is always enabled. ISP fees may apply and additional requirements may apply over time for updates. Go to <http://www.microsoft.com> for details.

To access the latest user guides, go to <http://www.hp.com/support>, and follow the instructions to find your product. Then select **Manuals**.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller.

For any further information or to request a full refund of the price of the computer, please contact your seller.

Not all features are available in all editions of Windows. This computer may require upgraded and/or separately purchased hardware, drivers and/or software to take full advantage of Windows functionality. Go to <http://www.microsoft.com> for details.

Table of contents

| | |
|---|-----------|
| 1 Product features | 1 |
| Standard configuration features | 1 |
| Front panel components | 1 |
| Rear panel components | 2 |
| Serial number location | 3 |
| 2 Illustrated parts catalog | 5 |
| Computer major components | 5 |
| Mass storage devices | 8 |
| Cables | 9 |
| Miscellaneous parts | 10 |
| 3 Routine care, SATA drive guidelines, and disassembly preparation | 11 |
| Electrostatic discharge information | 12 |
| Generating static electricity | 12 |
| Preventing electrostatic damage to equipment | 13 |
| Personal grounding methods and equipment | 13 |
| Grounding the work area | 13 |
| Recommended materials and equipment | 14 |
| Operating guidelines | 14 |
| Routine care | 16 |
| General cleaning safety precautions | 16 |
| Cleaning the computer case | 16 |
| Cleaning the keyboard | 16 |
| Cleaning the monitor | 17 |
| Cleaning the mouse | 17 |
| Service considerations | 18 |
| Tools and software requirements | 18 |
| Screws | 18 |
| Cables and connectors | 18 |
| Hard drives | 18 |

| | |
|---|-----------|
| Lithium coin cell battery | 19 |
| SATA hard drives | 19 |
| Cable management | 20 |
| 4 Removal and replacement procedures | 21 |
| Preparation for disassembly | 21 |
| Access panel | 21 |
| Optical drive | 22 |
| Front bezel | 23 |
| Hood sensor module | 24 |
| Memory modules (DIMMs) | 25 |
| Expansion card | 28 |
| Drive cage | 29 |
| Hard drive | 30 |
| Speaker | 34 |
| WLAN module | 35 |
| Solid-state drive | 37 |
| Fan shroud | 38 |
| Heat sink | 39 |
| Processor | 40 |
| Power supply | 42 |
| Battery | 43 |
| System board | 46 |
| 5 Troubleshooting without diagnostics | 49 |
| Before you call for technical support | 49 |
| Helpful hints | 50 |
| Solving general problems | 51 |
| Cannot access the Computer Setup (F10) Utility when booting the computer | 51 |
| Computer appears locked up and will not turn off when the power button is pressed | 51 |
| Computer will not respond to keyboard or mouse | 51 |
| Computer date and time display is incorrect | 51 |
| There is no sound or sound volume is too low | 52 |
| Cannot remove computer cover or access panel | 52 |
| Poor performance | 52 |
| Computer powered off automatically and the power light blinks red four times and then white two times | 53 |
| System does not turn on and the lights on the front of the computer are not blinking | 53 |
| Solving power problems | 55 |
| Power supply shuts down intermittently | 55 |

| | |
|--|----|
| Computer turned off automatically, power light blinks red two times followed by a two-second pause, and the computer beeps two times (Beeps stop after fifth iteration but lights continue blinking) | 55 |
| Power light blinks red four times followed by a two-second pause and the computer beeps four times (Beeps stop after fifth iteration but lights continue blinking) | 55 |
| Solving hard drive problems | 57 |
| Hard drive error occurs | 57 |
| Disk transaction problem | 57 |
| Drive not found (identified) | 57 |
| Nonsystem disk/NTLDR missing message | 57 |
| Computer will not boot from hard drive | 58 |
| Computer seems to be locked up | 58 |
| Solving audio problems | 59 |
| Sound cuts in and out | 59 |
| Sound does not come out of the speaker or headphones | 59 |
| Computer appears to be locked up while recording audio | 59 |
| Line-in jack is not functioning properly | 60 |
| Solving printer problems | 61 |
| Printer will not print | 61 |
| Printer will not turn on | 61 |
| Printer prints garbled information | 61 |
| Printer will not print | 61 |
| Solving keyboard and mouse problems | 63 |
| Keyboard commands and typing are not recognized by the computer | 63 |
| Mouse does not respond to movement or is too slow | 63 |
| Solving hardware installation problems | 64 |
| A new device is not recognized as part of the system | 64 |
| Computer will not start | 64 |
| Power light blinks red three times and then white two times | 65 |
| Solving network problems | 66 |
| Network driver does not detect network controller | 66 |
| Network status link light never blinks | 66 |
| Diagnostics reports a failure | 66 |
| Diagnostics passes, but the computer does not communicate with the network | 67 |
| Network controller stopped working when an expansion board was added to the computer | 67 |
| Network controller stops working without apparent cause | 67 |
| Cannot connect to network server when attempting remote system installation | 67 |
| System setup utility reports unprogrammed EEPROM | 68 |
| Solving memory problems | 69 |
| System will not boot or does not function properly after installing additional memory modules | 69 |
| Out of memory error | 69 |

| | |
|--|------------|
| Memory count during POST is wrong | 69 |
| Insufficient memory error during operation. | 70 |
| Power light blinks red five times followed by a two-second pause and the computer beeps five times (Beeps stop after fifth iteration but lights continue blinking) | 70 |
| Solving USB flash drive problems | 71 |
| USB flash drive is not seen as a drive letter in Windows | 71 |
| USB flash drive not found (identified) | 71 |
| System will not boot from USB flash drive | 71 |
| The computer boots to DOS after making a bootable flash drive | 71 |
| Solving internet access problems | 72 |
| Unable to connect to the internet | 72 |
| Cannot automatically launch internet programs | 72 |
| Solving software problems | 73 |
| Computer will not start up and the HP logo does not appear | 73 |
| “Illegal Operation has Occurred” error message is displayed | 73 |
| 6 Computer Setup (F10) Utility | 75 |
| Using Computer Setup (F10) Utilities | 75 |
| Computer Setup—Main | 76 |
| Computer Setup—Security | 79 |
| Computer Setup—Advanced | 83 |
| 7 POST error messages | 91 |
| POST numeric codes and text messages | 91 |
| Interpreting POST diagnostic front panel lights and audible codes | 95 |
| 8 Password security and resetting CMOS | 99 |
| Changing a setup or power-on password | 99 |
| Deleting a setup or power-on password | 100 |
| 9 Using HP PC Hardware Diagnostics | 101 |
| Using HP PC Hardware Diagnostics Windows (select products only) | 102 |
| Using an HP PC Hardware Diagnostics Windows hardware failure ID code | 102 |
| Accessing HP PC Hardware Diagnostics Windows | 103 |
| Accessing HP PC Hardware Diagnostics Windows from HP Help and Support | 103 |
| Accessing HP PC Hardware Diagnostics Windows from Support Assistant | 103 |
| Downloading HP PC Hardware Diagnostics Windows | 104 |
| Downloading the latest HP PC Hardware Diagnostics Windows version from HP | 104 |
| Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store | 104 |

| | |
|---|------------|
| Downloading HP Hardware Diagnostics Windows by product name or number (select products only) | 104 |
| Installing HP PC Hardware Diagnostics Windows | 104 |
| Using HP PC Hardware Diagnostics UEFI | 105 |
| Using an HP PC Hardware Diagnostics UEFI hardware failure ID code | 105 |
| Starting HP PC Hardware Diagnostics UEFI | 105 |
| Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive | 106 |
| Downloading the latest HP PC Hardware Diagnostics UEFI version | 106 |
| Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only) | 106 |
| Using Remote HP PC Hardware Diagnostics UEFI settings (select products only) | 107 |
| Downloading Remote HP PC Hardware Diagnostics UEFI | 108 |
| Downloading the latest Remote HP PC Hardware Diagnostics UEFI version | 108 |
| Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number | 108 |
| Customizing Remote HP PC Hardware Diagnostics UEFI settings | 108 |
| 10 Backing up, restoring, and recovering | 109 |
| Backing up information and creating recovery media | 110 |
| Using Windows tools for backing up | 110 |
| Using the HP Cloud Recovery Download Tool to create recovery media (select products only) | 110 |
| Restoring and recovering your system | 111 |
| Creating a system restore | 111 |
| Restoring and recovery methods | 111 |
| Recovering using HP Recovery media | 111 |
| Changing the computer boot order | 112 |
| Using HP Sure Recover (select products only) | 112 |
| 11 Statement of memory volatility | 113 |
| Current BIOS steps | 113 |
| Nonvolatile memory usage | 115 |
| Questions and answers | 117 |
| Using HP Sure Start (select products only) | 119 |
| 12 Power cord set requirements | 121 |
| General requirements | 121 |
| Japanese power cord requirements | 121 |
| Country-specific requirements | 121 |
| 13 Specifications | 123 |

Index 125

1 Product features

This chapter provides you with an overview of your computer's features.

Standard configuration features

To identify a typical computer configuration, read this section. Features vary depending on the model. For support assistance and to learn more about the hardware and software installed on your computer model, run the HP Support Assistant utility.



 **NOTE:** You can use this computer model in a tower orientation or a desktop orientation. In a tower orientation, you must use a stand for support.

Front panel components

To identify the front panel components, use this illustration and table.

Drive configuration varies by model. Some models have a bezel blank that covers one or more drive bays.




Table 1-1 Front panel components and their descriptions

| Item | Component | Item | Component |
|------|---|------|--|
| 1 | Slim optical drive (select products only) | 5 | Audio-out (headphone)/Audio-in (microphone) combo jack |
| 2 | Memory card reader (select products only) | 6 | Power button |
| 3 | USB SuperSpeed ports (2) | 7 | Hard drive activity light |
| 4 | USB Type-A ports (2) | | |

NOTE: The combo jack supports headphones, line output devices, microphones, line input devices, or CTIA style headsets.

NOTE: The light on the power button is normally white when the power is on. If the light flashes red, the computer displays a diagnostic code to indicate a problem. See the [refer to MSG sample] to interpret the code.

Rear panel components

To identify the rear panel components, use this illustration and table.




Table 1-2 Rear panel components and their descriptions

| Item | Component | Item | Component |
|------|-------------------------------------|------|--------------------------------|
| 1 | Serial port (optional) | 7 | HDMI port |
| 2 | Integrated accessory cable lock tab | 8 | DisplayPort™ monitor connector |
| 3 | Security lock | 9 | Optional port |

Table 1-2 Rear panel components and their descriptions (continued)

| Item | Component | Item | Component |
|------|--|------|--------------------------|
| 4 | RJ-45 (network) jack | 10 | USB ports (2) |
| 5 | Thumbscrew | 11 | USB SuperSpeed ports (3) |
| 6 | Audio-out jack for powered audio devices | 12 | Power cord connector |


NOTE: Your model might have additional optional ports available from HP.

When a graphics card is installed in one of the system board slots, you can use the video connectors on the graphics card or the integrated graphics on the system board. The specific graphics card installed and software configuration determines the behavior.

You can disable the system board graphics by changing settings in BIOS F10 Setup.

Serial number location

Each computer has a unique serial number and a product ID number that are located on the exterior of the computer. Keep these numbers available when contacting customer service for assistance.



2 Illustrated parts catalog

Use this information to determine the spare parts that are available for the computer.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <http://partsurfer.hp.com>, select your country or region, and then follow the on-screen instructions.

Computer major components

To identify the computer major components, use this illustration and table.




Table 2-1 Computer major components and their descriptions

| Item | Description |
|------|--|
| (1) | Access panel |
| (2) | Power supply: |
| | 210 W, 12 V, SFF, EPA92+ |
| | 180 W, SFF, EPA90 (gold) |
| (3) | Optical disc drive: |
| | DVD BD-WRITER DRIVE (9.5 mm, UST, 6×) |
| | DVD+/-RW SM DL DRIVE (9.5 mm, slim, tray load) |
| | DVD-ROM DRIVE (9.5 mm, slim, tray load) |

Table 2-1 Computer major components and their descriptions (continued)

| Item | Description |
|------------|--|
| | Optical disc drive, slim blank bezel (Pro, SFF) |
| | Optical disc drive, slim bezel assembly) |
| (4) | Memory modules (UDIMM, 1.2 V, DDR4-3200, NECC): |
| | 32 GB |
| | 16 GB |
| | 8 GB |
| | 4 GB |
| | Memory modules (UDIMM, 1.2 V, DDR4-2666, NECC): |
| | 32 GB |
| | 16 GB |
| | 8 GB |
| | 4 GB |
| (5) | System board (includes replacement thermal material): |
| | Equipped with the NetC and Windows® 10 operating systems |
| | Equipped with the NetC operating system |
| | Equipped with the Windows 10 operating system |
| | Not equipped with an operating system |
| (6) | WLAN module: |
| | Intel Wi-Fi 6 AX201 ax 2×2 + Bluetooth® 5 non-vPro™ WW |
| | Intel Wi-Fi 6 AX201 ax 2×2 + Bluetooth 5 vPro WW |
| | Realtek RTL8821CE ac 1×1 + Bluetooth 4.2 WW |
| | Realtek RTL8822CE ac 2×2 + Bluetooth 5 M.2 2230 WW |
| (7) | Solid-state drive |
| | 1 TB, M.2 2280, NVMe, SuperSpeed (SS) solid-state drive with triple layer cell (TLC) |
| | 512 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| | 512 GB, M.2 2280, PCIe-3×4, self-encrypting drive (SED) solid-state drive with TLC |
| | 512 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| | 256 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| | 256 GB, M.2 2280, PCIe-3×4, SED solid-state drive with TLC |
| | 256 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| | 128 GB, M.2 2280, PCIe, NVMe solid-state drive with TLC |
| | 16 GB, M.2 2280, PCIe-3×2, NVMe solid-state drive with TLC |
| | 256 GB, M.2 2280, PCIe + 16 GB 3D solid-state drive |

Table 2-1 Computer major components and their descriptions (continued)

| Item | Description |
|-------------|---|
| | 512 GB, M.2 2280, PCIe, NVMe + 32 GB 3D solid-state drive |
| (8) | System chassis (includes drive cage) |
| (9) | Fan shroud |
| (10) | Speaker (includes cable) |
| (11) | PCIe expansion card: |
| | AMD® Radeon® RX 550X 4 GB LP PCIe×16 DP+HDMI |
| | AMD Radeon RX 550X 4 GB DisplayPort card |
| | AMD Radeon R7 430 2 GB 2 DisplayPort 64 bit card |
| | AMD Radeon R7 430 2 GB DisplayPort VGA 64 bit card |
| | AMD Radeon R7 430 2 GB LP 2DP PCIe×16 64 bit GFX |
| | AMD Radeon R7 430 2 GB LP PCIe×16 DP VGA 64 bit |
| (12) | Heat sink |
| (13) | Hood sensor |
| (14) | Processor: |
| | Intel® Core® i7-10700 2.9 GHz, 8 cores, 65 W |
| | Intel Core i5-10600 3.3 GHz, 6 cores, 65 W |
| | Intel Core i5-10500 3.1 GHz, 6 cores, 65 W |
| | Intel Core i5-10400 2.9 GHz, 6 cores, 65 W |
| | Intel Core i3-10320 3.8 GHz, 4 cores, 65 W |
| | Intel Core i3-10300 3.7 GHz, 4 cores, 65 W |
| | Intel Core i3-10100 3.6 GHz, 4 cores, 65 W |
| | Intel Pentium® Gold G6600 4.2 GHz, 2 cores, 58 W |
| | Intel Pentium Gold G6500 4.1 GHz, 2 cores, 58 W |
| | Intel Pentium Gold G6400 4.0 GHz, 2 cores, 58 W |
| | Intel Celeron® G5920 3.5 GHz, 2 cores, 58 W |
| | Intel Celeron G5900 3.4 GHz, 2 cores, 58 W |
| (15) | Hard drive: |
| | 2 TB, SATA, 7200 RPM, 3.5 in hard drive |
| | 2 TB, SATA, 5400 RPM, 7.0 mm hard drive |
| | 1 TB, SATA, 7200 RPM, 3.5 in hard drive |
| | 1 TB, SATA, 7200 RPM, 9.5 mm hard drive |
| | 500 GB, SATA, 7200 RPM, 3.5 in |
| | 500 GB, SATA, 7200 RPM, 7.0 mm |

Table 2-1 Computer major components and their descriptions (continued)

| Item | Description |
|------|--------------------------------------|
| | 500 GB, SATA, 7200 RPM, 7.0 mm, FIPS |
| | 500 GB, 7200 RPM, 7.0 mm, SED, Opal2 |
| (16) | Front bezel |

Mass storage devices

To identify the available hard drives, solid-state drives, and optical drives, use this table.

Table 2-2 Mass storage devices and their descriptions

| Description |
|--|
| Hard drives: |
| 2 TB, SATA, 7200 RPM, 3.5 in hard drive |
| 2 TB, SATA, 5400 RPM, 7.0 mm hard drive |
| 1 TB, SATA, 7200 RPM, 3.5 in hard drive |
| 1 TB, SATA, 7200 RPM, 9.5 mm hard drive |
| 500 GB, SATA, 7200 RPM, 3.5 in |
| 500 GB, SATA, 7200 RPM, 7.0 mm |
| 500 GB, SATA, 7200 RPM, 7.0 mm, FIPS |
| 500 GB, 7200 RPM, 7.0 mm, SED, Opal2 |
| Solid-state drives: |
| 1 TB, M.2 2280, NVMe, SuperSpeed (SS) solid-state drive with triple layer cell (TLC) |
| 512 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| 512 GB, M.2 2280, PCIe-3x4, self-encrypting drive (SED) solid-state drive with TLC |
| 512 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| 256 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe-3x4, SED solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| 128 GB, M.2 2280, PCIe, NVMe solid-state drive with TLC |
| 16 GB, M.2 2280, PCIe-3x2, NVMe solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe + 16 GB 3D solid-state drive |
| 512 GB, M.2 2280, PCIe, NVMe + 32 GB 3D solid-state drive |
| Optical disc drives: |
| DVD BD-WRITER DRIVE (9.5 mm, UST, 6x) |
| DVD+/-RW SM DL DRIVE (9.5 mm, slim, tray load) |

Table 2-2 Mass storage devices and their descriptions (continued)

| Description |
|---|
| DVD-ROM DRIVE (9.5 mm, slim, tray load) |
| Optical disc drive, slim blank bezel (Pro, SFF) |
| Optical disc drive, slim bezel assembly) |

Cables

To identify the computer cables, use this table.

Table 2-3 Cables and their descriptions

| Description |
|---|
| Adapters: |
| 2.5 in slim optical disc drive bay adapter (SFF) |
| HP DisplayPort-to-HDMI 2.0 adapter |
| HP DisplayPort-to-HDMI 2.0 adapter |
| USB-to-Serial adapter (Sunix) |
| USB-Type C-to-USB-Type A connector adapter |
| Cables: |
| DisplayPort-to-DisplayPort 1.2 (1.8 m, black) |
| DisplayPort-to-DVI |
| DisplayPort-to-VGA |
| DVI-to-DVI-D (1.8 m, white) |
| SATA 7.5 in cable assembly straight-to-straight |
| SATA 7P 250 mm cable Intel/AMD |
| SATA 7P 175 mm cable RA |
| SATA power cable (175/315 mm) |
| SATA power cable (20/330/70 mm) |
| Wireless Antenna Cable Kit, M.2 |
| Keyboards: |
| HP antimicrobial slim business keyboard |
| HP PS/2 slim Windows 8 keyboard |
| HP USB keyboard |
| HP USB slim SmartCard CCID keyboard |
| HP wireless Windows 8 keyboard, mouse, and dongle |
| USB ME keyboard |

Table 2-3 Cables and their descriptions (continued)

| Description |
|--|
| USB keyboard with U.S. layout |
| USB PS/2 BFR-PVC washable Windows 8 keyboard |
| USB unbranded keyboard |
| Mouse: |
| HP PS/2 optical mouse |
| HP USB antimicrobial mouse |
| HP USB fingerprint mouse |
| HP USB hardened mouse |
| HP USB laser mouse |
| HP USB mouse |
| HP USB optical mouse |
| USB PS/2 M12 washable mouse ME |
| Power cord (C13) |

Miscellaneous parts

To identify the various computer parts, use this table.

Table 2-4 Miscellaneous parts and their descriptions

| Description |
|----------------------------------|
| Light cover |
| Mouse |
| USB, laser |
| USB, optical |
| Keyboard |
| USB |
| Wireless + cable adapter + mouse |

3 Routine care, SATA drive guidelines, and disassembly preparation

This information provides general service information for the computer. Adherence to the procedures and precautions is essential for proper service.

 **IMPORTANT:** When the computer is plugged into an AC power source, voltage is always applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs.

An electronic device exposed to electrostatic discharge (ESD) might not appear to be affected at all and can work perfectly throughout a normal cycle. The device might function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

 **IMPORTANT:** To prevent damage to the device when you are removing or installing internal components, observe these precautions:

Keep components in their electrostatic-safe containers until you are ready to install them.

Before touching an electronic component, discharge static electricity by using the guidelines described in this section.

Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.

If you remove a component, place it in an electrostatic-safe container.

Generating static electricity

This table shows how humidity affects the electrostatic voltage levels generated by different activities. A product can be degraded by 700 V.

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Table 3-1 Static electricity occurrence based on activity and humidity

| Event | Relative humidity | | |
|---|-------------------|----------|----------|
| | 55% | 40% | 10% |
| Walking across carpet | 7,500 V | 15,000 V | 35,000 V |
| Walking across vinyl floor | 3,000 V | 5,000 V | 12,000 V |
| Motions of bench worker | 400 V | 800 V | 6,000 V |
| Removing DIPs (dual in-line packages) from plastic tube | 400 V | 700 V | 2,000 V |
| Removing DIPs from vinyl tray | 2,000 V | 4,000 V | 11,500 V |
| Removing DIPs from polystyrene foam | 3,500 V | 5,000 V | 14,500 V |
| Removing bubble pack from PCB (printed circuit board) | 7,000 V | 20,000 V | 26,500 V |
| Packing PCBs in foam-lined box | 5,000 V | 11,000 V | 21,000 V |

Multiple electric components can be packaged together in plastic tubes, trays, or polystyrene foam.

Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent static electricity damage to electronic components.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal grounding methods and equipment

Use this equipment to prevent static electricity damage to electronic components.

- **Wrist straps** are flexible straps with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance in the ground cords. To provide proper ground, a strap must be worn snug against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance between the operator and ground.

Table 3-2 Static shielding protection levels

| Static shielding protection levels | |
|------------------------------------|---------|
| Method | Voltage |
| Antistatic plastic | 1,500 |
| Carbon-loaded plastic | 7,500 |
| Metallized laminate | 15,000 |

Grounding the work area

To prevent static damage at the work area, use these precautions.

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.

- Keep work area free of nonconductive materials such as ordinary plastic assembly aids and polystyrene foam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

Recommended materials and equipment

HP recommends the these materials and equipment to prevent static electricity.

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of $1\text{ M}\Omega \pm 10\%$ resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing $1\text{ M}\Omega \pm 10\%$ resistance
- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

Operating guidelines

This information details how to prevent overheating and to help prolong the life of the computer.

- Keep the computer away from excessive moisture, direct sunlight, and extremes of heat and cold.
- Operate the computer on a sturdy, level surface. Leave a 10.2 cm (4 inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.
- Never restrict the airflow into the computer by blocking any vents or air intakes. Do not place the keyboard, with the keyboard feet down, directly against the front of the desktop unit as this also restricts airflow.
- Occasionally clean the air vents on all vented sides of the computer. Lint, dust, and other foreign matter can block the vents and limit the airflow. Be sure to unplug the computer before cleaning the air vents.
- Never operate the computer with the cover or side panel removed.

- Do not stack computers on top of each other or place computers so near each other that they are subject to each other's recirculated or preheated air.
- If the computer is to be operated within a separate enclosure, intake and exhaust ventilation must be provided on the enclosure, and the same operating guidelines listed previously still apply.
- Keep liquids away from the computer and keyboard.
- Never cover the ventilation slots on the monitor with any type of material.
- Install or enable power management functions of the operating system or other software, including Sleep states.

Routine care

Use this information to properly care for your computer.

General cleaning safety precautions

Use this information to safely clean your computer.

1. Never use solvents or flammable solutions to clean the computer.
2. Never immerse any parts in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
3. Always unplug the computer when cleaning with liquids or damp cloths.
4. Always unplug the computer before cleaning the keyboard, mouse, or air vents.
5. Disconnect the keyboard before cleaning it.
6. Wear safety glasses equipped with side shields when cleaning the keyboard.

Cleaning the computer case

Follow all safety precautions before cleaning the computer case.

To clean the computer case, follow these procedures:

- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dishwashing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is needed because the alcohol evaporates quickly and does not leave a residue.
- After cleaning, always wipe the unit with a clean, lint-free cloth.
- Occasionally clean the air vents on the computer. Lint and other foreign matter can block the vents and limit the airflow.

Cleaning the keyboard

Use this information to properly clean the keyboard. Follow all safety precautions before cleaning the keyboard.

To clean the tops of the keys or the keyboard body, follow the procedures described in [Cleaning the computer case on page 16](#).

When cleaning debris from under the keys, review all rules in [General cleaning safety precautions on page 16](#) before following these procedures.

 **CAUTION:** Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

- You can remove visible debris underneath or between the keys by vacuuming or shaking.
- You can use canned, pressurized air to clean debris from under the keys. Use caution because too much air pressure can dislodge lubricants applied under the wide keys.

- If you remove a key, use a specially designed key puller to prevent damage to the keys. This tool is available through many electronic supply outlets.



IMPORTANT: Never remove a wide leveled key (like the space bar) from the keyboard. If these keys are improperly removed or installed, the keyboard might not function properly.

- You can clean under a key with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Use tweezers to remove any fibers or dirt in confined areas. Allow the parts to air dry before reassembly.

Cleaning the monitor

Use this information to properly clean the monitor.

- Wipe the monitor screen with a clean cloth moistened with water or with a towelette designed for cleaning monitors. Do not use sprays or aerosols directly on the screen; the liquid can seep into the housing and damage a component. Never use solvents or flammable liquids on the monitor.
- To clean the monitor body, follow the procedures in [Cleaning the computer case on page 16](#).

Cleaning the mouse

Use this information to properly clean the mouse.

Before cleaning the mouse, be sure that the power to the computer is turned off.

- Clean the mouse ball by first removing the retaining plate and the ball from the housing. Pull out any debris from the ball socket and wipe the ball with a clean, dry cloth before reassembly.
- To clean the mouse body, follow the procedures in [Cleaning the computer case on page 16](#).

Service considerations

Keep these considerations in mind during the disassembly and assembly of the computer.

Tools and software requirements

Servicing the computer requires these tools.

- Torx T-15 screwdriver
- Flat-bladed screwdriver (can sometimes be used in place of the Torx screwdriver)
- Phillips P1 screwdriver
- Nonconductive, nonmarking pry tool
- Diagnostics software

Screws

The screws used in the computer are not interchangeable. They could have standard or metric threads and might be of different lengths.

If you use an incorrect screw during the reassembly process, it can damage the unit. HP strongly recommends that you keep all screws that you remove during disassembly with the removed part and then return them to their proper locations.

 **IMPORTANT:** As you remove each subassembly from the computer, place it away from the work area to prevent damage.

Cables and connectors

Use this information properly handle cables.

Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector whenever possible. In all cases, avoid bending or twisting the cables, and route the cables so that they cannot be caught or snagged by parts being removed or replaced.

 **IMPORTANT:** When servicing this computer, be sure to place cables in their proper location during the reassembly process. Improper cable placement can damage the computer.

Hard drives

Handle hard drives as delicate, precision components, avoiding all physical shock and vibration. This advice applies to failed drives as well as replacement spares.

- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the computer.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.

- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector.
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

Lithium coin cell battery

The battery that comes with the computer provides power to the real-time clock and has a minimum lifetime of approximately three years.

See the appropriate removal and replacement chapter for the chassis that you are working on for instructions on the replacement procedures.

WARNING! This computer contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose of in water or fire, or expose it to temperatures higher than 140°F (60°C). Do not attempt to recharge the battery.

NOTE: Do not dispose of batteries, battery packs, and accumulators with general household waste. To forward them to recycling centers or proper disposal, use the public collection system or return them to HP, their authorized partners, or their agents.

SATA hard drives

The Self Monitoring Analysis and Recording Technology (SMART) ATA drives for the HP Personal Computers have built-in drive failure prediction that warns the user or network administrator of an impending failure or crash of the hard drive.

The SMART drive tracks fault prediction and failure indication parameters such as reallocated sector count, spin retry count, and calibration retry count. If the drive determines that a failure is imminent, it generates a fault alert.

Table 3-3 SATA hard drive characteristics

| Serial ATA hard drive characteristics | |
|---|-------------------|
| Number of pins/conductors in data cable | 7/7 |
| Number of pins in power cable | 15 |
| Maximum data cable length | 100 cm (39.37 in) |
| Data interface voltage differential | 400 mV–700 mV |
| Drive voltages | 3.3 V, 5 V, 12 V |
| Jumpers for configuring drive | N/A |
| Data transfer rate | 6.0 Gbps |

Always use an HP-approved SATA 6.0 Gbps cable because it is fully backwards compatible with the SATA 1.5 Gbps drives. Current HP desktop products ship with SATA 6.0 Gbps hard drives.

SATA data cables are susceptible to damage if overflexed. Never crease a SATA data cable and never bend it tighter than a 30 mm (1.18 in) radius.

The SATA data cable is a thin, seven-pin cable designed to transmit data for only a single drive.

Cable management

Always follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heat sink.
- Keep cables clear of sliding or moveable parts to prevent them from being cut or crimped when the parts are moved.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases can damage the wires.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.

4 Removal and replacement procedures

Adherence to these procedures and precautions is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.

 **NOTE:** Not all features listed in this guide are available on all computers.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <http://partsurfer.hp.com>, select your country or region, and then follow the on-screen instructions.

Preparation for disassembly

Use this information to properly prepare to disassemble and reassemble the computer.

See [Routine care, SATA drive guidelines, and disassembly preparation on page 11](#) for initial safety procedures.

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.

 **IMPORTANT:** Turn off the computer before disconnecting any cables.

Regardless of the power state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems, the cooling fan is on even when the computer is in the Standby or Suspend modes. Always disconnect the power cord before servicing a unit.

2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer
4. If the computer is on a stand, remove the computer from the stand.

 **CAUTION:** Beware of sharp edges inside the chassis.

 **NOTE:** During disassembly, label each cable as you remove it, and note its position and routing. Keep all screws with the removed components.

Access panel


To remove the access panel, use these procedures.

Before removing the access panel, follow these steps:

- ▲ Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).

Remove the access panel:

- ▲ Loosen the thumbscrew **(1)** on the rear of the computer, slide the panel forward **(2)**, and lift it off the computer **(3)**.



To install the access panel, reverse the removal procedure.

Optical drive

To remove the optical drive, use these procedures.


Before removing the optical drive, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the optical drive:

1. Disconnect the power cable **(1)** and data cable **(2)** from the rear of the optical drive.

2. Push the green release latch (3) on the right rear side of the drive toward the center of the drive, and then slide the drive forward and out of the bay (4).



3. If you are installing an optical drive in a bay covered by a bezel blank, remove the front bezel ([Front bezel on page 23](#)).
4. Install the release latch onto the drive. Align the small pin on the release latch with the small hole on the side of the drive, and press the latch firmly onto the drive.



5. Connect the power cable and data cable to the rear of the drive, and then connect the opposite end of the data cable to one of the SATA connectors on the system board labeled SATA1 or SATA2.

Front bezel


To remove the front bezel, use these procedures.

Before removing the front bezel, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the front bezel:

1. Disengage the three tabs **(1)** on the top of the front bezel from the system chassis.
2. Swing the top edge of the front bezel **(2)** away from the system chassis.



3. Remove the bezel from the access panel.

To install the front bezel, reverse the removal procedure.

Hood sensor module

To remove the hood sensor module, use these procedures. The hood sensor module is located on the rear panel of the computer chassis.


Before removing the hood sensor module, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the hood sensor module:

1. Disconnect the hood sensor module cable **(1)** from the system board.

2. Lift to remove the hood sensor module (2) from the system chassis.



To install the hood sensor module, reverse the removal procedures.

Memory modules (DIMMs)

To remove the memory modules, use this information and procedures.

Table 4-1 Memory module descriptions

| Description |
|--|
| Memory module (UDIMM, 1.2 V, DDR4-3200, NECC) |
| 32 GB |
| 16 GB |
| 8 GB |
| 4 GB |
| Memory module (UDIMM, 1.2 V, DDR4-2666, NECC) |
| 32 GB |
| 16 GB |
| 8 GB |
| 4 GB |

The memory sockets on the system board are populated with at least one preinstalled memory module. To achieve the maximum memory support, you can populate the system board with up to 128 GB of memory configured in a high-performing dual-channel mode.

For proper system operation, the DIMMs must adhere to the following specifications:

- Industry-standard 288-pin
- Unbuffered non-ECC PC4-19200 DDR4-2666/3200 MHz-compliant

- 1.2 V DDR4-SDRAM memory modules
- CAS latency 17 DDR4 2666/3200 MHz (17-17-17 timing)
- Mandatory JEDEC SPD information

The computer supports the following setups:

- 512 Mbit, 1 Gbit, 2 Gbit, and 4 Gbit non-ECC memory technologies
- Single-sided and double-sided memory modules
- Memory modules constructed with ×8 and ×16 DDR devices; memory modules constructed with ×4 SDRAM are not supported



NOTE: The system does not operate properly if you install unsupported memory modules.

There are four memory sockets on the system board, with two sockets per channel. The sockets are labeled DIMM1, DIMM2, DIMM3, and DIMM4. Sockets DIMM1 and DIMM2 operate in memory channel B. Sockets DIMM3 and DIMM4 operate in memory channel A.

The system automatically operates in single-channel mode, dual-channel mode, or flex mode, depending on how the DIMMs are installed.



NOTE: Single-channel and unbalanced dual-channel memory configurations results in inferior graphics performance.

- The system operates in single-channel mode if the DIMM sockets are populated in one channel only.
- The system will operate in a higher-performing dual-channel mode if the total memory capacity of the DIMMs in channel A is equal to the total memory capacity of the DIMMs in channel B. The technology and device width can vary between the channels. For example, if channel A is populated with two 1 GB DIMMs and channel B is populated with one 2 GB DIMM, the system will operate in dual-channel mode.
- The system operates in flex mode if the total memory capacity of the DIMMs in channel A is not equal to the total memory capacity of the DIMMs in channel B. In flex mode, the channel populated with the least amount of memory describes the total amount of memory assigned to dual channel and the remainder is assigned to single channel. For optimal speed, the channels should be balanced so that the largest amount of memory is spread between the two channels. If one channel will have more memory than the other, the larger amount should be assigned to channel A. For example, if you are populating the sockets with one 2 GB DIMM, and three 1 GB DIMMs, channel A should be populated with the 2 GB DIMM and one 1 GB DIMM, and channel B should be populated with the other two 1 GB DIMMs. With this configuration, 4 GB runs as dual channel and 1 GB will run as single channel.
- In any mode, the maximum operational speed is determined by the slowest DIMM in the system.

 **IMPORTANT:** You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present can cause irreparable damage to the memory modules or system board.

The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion, oxidation, or both resulting from having incompatible metals in contact with each other.

Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, see [Electrostatic discharge information on page 12](#).


When handling a memory module, be careful not to touch any of the contacts. Doing so can damage the module.

Before replacing the memory modules, follow these steps:


1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Replace a memory module:

1. To remove a memory module, open both latches of the memory module socket (**1**), and then remove the memory module from the socket (**2**).



2. To install a memory module, open both latches of the memory module socket (1), and insert the memory module into the socket (2). Press the module down into the socket so that the module is fully inserted and properly seated. Be sure that the latches are in the closed position (3).



 **NOTE:** A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

Populate the black DIMM sockets before the white DIMM sockets.

For maximum performance, populate the sockets so that the memory capacity is spread as equally as possible between channel A and channel B.

The computer automatically recognizes the additional memory when you turn on the computer.

Expansion card

The computer has one PCI Express $\times 1$ expansion socket, two PCI Express $\times 16$ expansion sockets, and one PCI Express $\times 8$ expansion socket.

 **NOTE:** You can install a PCI Express $\times 1$, $\times 8$, or $\times 16$ expansion card in the PCI Express $\times 16$ socket.

For dual graphics card configurations, the first (primary) card must be installed in the PCI Express $\times 16$ socket.


 **NOTE:** Before removing an installed expansion card, disconnect any cables that are attached to the expansion card.

Before replacing the expansion modules, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

To replace or add an expansion card:

1. Release the slot cover retention latch (1) that secures the slot covers by lifting the tab on the latch and rotating the latch to the open position.
2. If you are removing a PCI Express ×16 card, pull the retention arm on the back of the expansion socket away from the card (2).
3. Carefully rock the card back and forth until the connectors pull free from the socket. Lift the card straight up (3) and then away from the inside of the chassis to remove it. Be sure not to scrape the card against other components.



4. Locate the correct vacant expansion socket on the system board and the corresponding expansion slot on the back of the computer chassis.
5. Before installing an expansion card, remove the expansion slot cover or the existing expansion card.
6. Store the removed card in antistatic packaging.
7. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.

 **IMPORTANT:** After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

8. After installing an expansion card, connect external cables to the installed card and internal cables to the system board, if needed.
9. Reassemble and reconfigure the computer, if necessary.

Drive cage


To remove the drive cage, use these procedures. The drive cage is located next to the heat sink. The drive cage is secured with three slotted Torx screws.

Before removing the drive cage, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the drive cage:

1. Press the drive cage release button (1) to allow the drive cage to be released.
2. Swing the drive cage (2) up and toward the front of the system chassis.



To secure the drive cage, reverse the release procedure.

Hard drive

To remove the hard drive, use these procedures.

Table 4-2 descriptions, hard drive

| Description |
|---|
| 2 TB, SATA, 7200 RPM, 3.5 in hard drive |
| 2 TB, SATA, 5400 RPM, 7.0 mm hard drive |
| 1 TB, SATA, 7200 RPM, 3.5 in hard drive |
| 1 TB, SATA, 7200 RPM, 9.5 mm hard drive |
| 500 GB, SATA, 7200 RPM, 3.5 in |
| 500 GB, SATA, 7200 RPM, 7.0 mm |
| 500 GB, SATA, 7200 RPM, 7.0 mm, FIPS |
| 500 GB, 7200 RPM, 7.0 mm, SED, Opal2 |
| Grommets, hard drive |

 **NOTE:** Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.


Before removing the hard drive, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).


3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the front bezel ([Front bezel on page 23](#)).
5. Release the drive cage ([Drive cage on page 29](#)).

Remove the hard drive:


1. Release the hard drive power and data cables from the retention clips (1) and (2) built into the drive cage.
2. Disconnect the hard drive power cable (3) and data cable (4) from the system board.




3. Pull the release lever outward (1).
4. While pulling the release lever outward, slide the drive to the left (2) until it stops, and then remove the hard drive from the drive cage.




5. Disconnect the hard drive power cable (1) and data cable (2) from the hard drive.




6. To install a new hard drive, you must transfer the silver and blue isolation mounting guide screws from the old hard drive to the new hard drive.




7. You can also install a 2.5 inch hard drive into a 3.5 inch drive bay using an adapter bracket similar to the following example. Slide the 2.5 inch drive into the 3.5 inch adapter bracket.



8. Secure the drive to the bay adapter bracket by installing four black M3 adapter bracket screws through the underside of the bracket and into the drive.



9. Install four 6-32 silver-and-blue mounting screws in the adapter bracket (two on each side of the bracket).



Speaker


To remove the speaker, use these procedures. A single speaker is located on the left side of the computer behind the front bezel, inside the chassis. It is secured by a white peg that you pull out to release.

Before removing the speaker, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the speaker:

1. Disconnect the speaker cable from the system board (1).
2. Release the speaker from the rubber retention clips (2) built into the system chassis.
3. Remove the speaker (3).



To install the speaker, reverse the removal procedures.

WLAN module

To remove the WLAN module, use these procedures.

Table 4-3 WLAN module descriptions

| Description |
|--|
| Intel Wi-Fi 6 AX201 ax 2×2 + Bluetooth 5 non-vPro WW |
| Intel Wi-Fi 6 AX201 ax 2×2 + Bluetooth 5 vPro WW |
| Realtek RTL8821CE ac 1×1 + Bluetooth 4.2 WW |
| Realtek RTL8822CE ac 2×2 + Bluetooth 5 M.2 2230 WW |

The WLAN module is located near the memory modules.

 **NOTE:** WLAN module appearance can vary.

Before removing the WLAN module, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).
3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the front bezel ([Front bezel on page 23](#)).
5. Release the drive cage ([Drive cage on page 29](#)).


Remove the WLAN module:

1. Disconnect the antenna cables from the module **(1)**.


 **NOTE:** The WLAN antenna cable labeled 1/MAIN connects to the WLAN module Main terminal. The WLAN antenna cable labeled 2/AUX connects to the WLAN module Aux terminal.

2. Remove the screw **(2)** that secures the module to the computer.

3. Pull the module to remove it from the socket (3).



4. If the WLAN antenna is not connected to the terminal on the WLAN module, a protective sleeve must be installed on the antenna connector, as shown in the following illustration.



To install the WLAN module, reverse the removal procedure.

 **NOTE:** WLAN modules are designed with a notch to prevent incorrect insertion.

Solid-state drive

To remove the solid-state drive module, use these procedures.

Table 4-4 Solid-state drive module descriptions

| Description |
|--|
| 1 TB, M.2 2280, NVMe, SuperSpeed (SS) solid-state drive with triple layer cell (TLC) |
| 512 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| 512 GB, M.2 2280, PCIe-3×4, self-encrypting drive (SED) solid-state drive with TLC |
| 512 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| 256 GB, M.2 2280, PCIe, NVMe, SS solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe-3×4, SED solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe, NVMe, value solid-state drive |
| 128 GB, M.2 2280, PCIe, NVMe solid-state drive with TLC |
| 16 GB, M.2 2280, PCIe-3×2, NVMe solid-state drive with TLC |
| 256 GB, M.2 2280, PCIe + 16 GB 3D solid-state drive |
| 512 GB, M.2 2280, PCIe, NVMe + 32 GB 3D solid-state drive |


Before removing the solid-state drive module, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).
3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the front bezel ([Front bezel on page 23](#)).
5. Release the drive cage ([Drive cage on page 29](#)).

Remove the solid-state drive module:

1. Remove the screw that secures the drive **(1)**.

2. Pull the drive out of the system board connector (2).



To install the solid-state drive module, reverse the removal procedure.

 **NOTE:** Solid-state drive modules are designed with a notch to prevent incorrect insertion.

Fan shroud

To remove the fan shroud, use these procedures.


Before removing the fan shroud, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).

Remove the fan shroud:

1. Release the fan shroud by pressing out on the two release tabs (1).

2. Remove the fan shroud (2).



To install the fan shroud, reverse the removal procedures.

Heat sink

To remove the heat sink, use these procedures.

 **IMPORTANT:** The bond between the heat sink and the processor can be very tight.

If the computer will turn on, before removing the heat sink, turn on the computer until it warms the heat sink. Warming the heat sink loosens the bond between the heat sink and the processor, thereby making it easier to separate them.

Make sure not to pull the processor out of the socket when you lift the heat sink, especially if you cannot warm the heat sink before removal. Inadvertently removing the processor can damage the pins.

Before removing the heat sink, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).
3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the fan shroud ([Fan shroud on page 38](#)).


Remove the heat sink:

1. Disconnect the fan cable (1) from the system board.

- In the order indicated on the heat sink, loosen the four captive Torx screws (2), and then lift the heat sink out of the computer (3).

 **IMPORTANT:** Be sure to loosen the screws in the order indicated by the numbers stamped on the heat sink.

IMPORTANT: For optimum thermal performance, be sure not to touch the thermal grease on the surface of the processor or the heat sink.



 **IMPORTANT:** Tighten the heat sink retention screws in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor to avoid damage that could require replacing the system board.

To replace the heat sink, reverse the removal procedures.

Processor

To remove the processor, use these procedures.

Table 4-5 Processor descriptions

| Description |
|---|
| Intel Core i7-10700 2.9 GHz, 8 cores, 65 W |
| Intel Core i5-10600 3.3 GHz, 6 cores, 65 W |
| Intel Core i5-10500 3.1 GHz, 6 cores, 65 W |
| Intel Core i5-10400 2.9 GHz, 6 cores, 65 W |
| Intel Core i3-10320 3.8 GHz, 4 cores, 65 W |
| Intel Core i3-10300 3.7 GHz, 4 cores, 65 W |
| Intel Core i3-10100 3.6 GHz, 4 cores, 65 W |
| Intel Pentium Gold G6600 4.2 GHz, 2 cores, 58 W |
| Intel Pentium Gold G6500 4.1 GHz, 2 cores, 58 W |
| Intel Pentium Gold G6400 4.0 GHz, 2 cores, 58 W |

Table 4-5 Processor descriptions (continued)

| Description |
|--|
| Intel Celeron G5920 3.5 GHz, 2 cores, 58 W |
| Intel Celeron G5900 3.4 GHz, 2 cores, 58 W |

Before removing the processor, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).
3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the fan shroud ([Fan shroud on page 38](#)).
5. Remove the heat sink ([Heat sink on page 39](#)).


Remove the processor:

1. Slide the locking lever **(1)** to the right until it is free to swing back, and then swing the locking lever **(2)** to its full open position.
2. Remove the Torx screw **(3)** that secures the microprocessor retainer in place.
3. Raise and rotate the microprocessor retainer **(4)** to its fully open position.

- Carefully lift the processor from the socket (5).

 **IMPORTANT:** Do not handle the pins in the processor socket. These pins are fragile, and handling them could cause irreparable damage. If pins are damaged, you might have to replace the system board.

The heat sink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.



To replace the processor, reverse the removal procedures.

 **NOTE:** After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. You can find the latest system BIOS on the web at: <https://support.hp.com/us.en>.

Power supply


To remove the power supply, use these procedures.

Before removing the power supply, follow these steps:


- Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
- Remove the access panel ([Access panel on page 21](#)).
- Remove the optical drive ([Optical drive on page 22](#)).
- Remove the front bezel ([Front bezel on page 23](#)).
- Remove the drive cage ([Drive cage on page 29](#)).

Remove the power supply:

- Disconnect the power supply P1 (1), P2 (2), and P3 cables (3) from the system board.



2. From the computer rear panel, remove the four screws (1) that secure the power supply to the system chassis.
3. From the front of the computer, press and hold the power supply release tab (2).
4. While holding the power supply release tab, slide the power supply (3) toward the front of the computer until it disengages from the system chassis.
5. Remove the power supply (4).



To install the power supply, reverse the removal procedures.

Battery

To remove the battery, use these procedures. The battery that comes with the computer provides power to the real-time clock. When replacing the battery, use a battery equivalent to the battery originally installed in the computer. The computer comes with a 3 V lithium coin cell battery.

⚠ WARNING! The computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

Do not attempt to recharge the battery.

Do not expose to temperatures higher than 60°C (149°F).

Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.

Replace the battery only with the HP spare part that is designated for this product.

📝 IMPORTANT: Before replacing the battery, back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings are cleared.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.

📝 NOTE: You can extend the lifetime of the lithium battery by plugging the computer into an AC outlet. The lithium battery is used only when the computer is not connected to AC power.


HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, go to <http://www.hp.com/recycle>.

Before removing the battery, follow these steps:

1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).


Remove the battery:

1. Locate the battery and battery holder on the system board.



2. Depending on the type of battery holder on the system board, complete the following instructions to replace the battery.

3. **Type 1:** Lift the battery out of its holder.




4. Slide the replacement battery into position, positive side up. The battery holder automatically secures the battery in the proper position.
5. **Type 2:** To release the battery from its holder, squeeze the metal clamp that extends above one edge of the battery (1). When the battery pops up, lift it out (2).



6. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up (1). Push the other edge down until the clamp snaps over the other edge of the battery (2).



7. **Type 3:** Pull back the clip (1) that is holding the battery in place, and remove the battery (2).



8. Insert the new battery and position the clip back into place.

System board

To remove the system board, use these procedures.

 **NOTE:** All system board spare part kits include replacement thermal material.


 **NOTE:** System board appearance can vary.

Before removing the system board, follow these steps:


1. Prepare the computer for disassembly ([Preparation for disassembly on page 21](#)).
2. Remove the access panel ([Access panel on page 21](#)).
3. Remove the optical drive ([Optical drive on page 22](#)).
4. Remove the front bezel ([Front bezel on page 23](#)).
5. Release the drive cage ([Drive cage on page 29](#)).
6. Remove the fan shroud ([Fan shroud on page 38](#)).
7. Remove the heat sink ([Heat sink on page 39](#)).

Remove the system board:

1. Remove the six Torx screws that secure the system board to the system chassis.



2. Lift the rear edge of the system board (1) and swing it up and forward until it rests at an angle and clears the system chassis rear panel.
3. Slide the system board (2) up and back at an angle and remove it from the system chassis.



To install the system board, reverse the removal procedures.

 **NOTE:** When replacing the system board, you must change the chassis serial number in the BIOS.

When replacing the system board, you must reprogram the SMBIOS information about the affected computer. Failure to reprogram the board will result in eventual failure, such as an activation failure (need to reactivate the system) or a system recovery failure.

Update SMBIOS information in Computer Setup.

5 Troubleshooting without diagnostics

Use these sections to identify and correct minor problems.

⚠ CAUTION: Misuse of the computer or failure to establish a safe and comfortable work environment may result in discomfort or serious injury. See the *Safety & Comfort Guide* at <http://www.hp.com/ergo> for more information about choosing a workspace and creating a safe and comfortable work environment. For more information, see the *Safety & Regulatory Information* guide.

Before you call for technical support

If you are having problems with the computer, try these solutions to isolate the exact problem before calling for technical support.

- Run the HP diagnostic tool.
- Run the hard drive self-test in Computer Setup.
- Check the power light on the front of the computer to see if it is blinking red. The blinking lights are error codes that will help you diagnose the problem.
- If you are working on a network, plug another computer with a different cable into the network connection. There might be a problem with the network plug or cable.
- If you recently added new hardware, remove the hardware and see if the computer functions properly.
- If you recently installed new software, uninstall the software and see if the computer functions properly.
- Boot the computer to the Safe Mode to see if it will boot without all of the drivers loaded. When booting the operating system, use “Last Known Configuration.”
- See the comprehensive online technical support at <http://www.hp.com/support>.

To assist you in resolving problems online, HP Instant Support Professional Edition provides you with self-solve diagnostics. If you need to contact HP support, use HP Instant Support Professional Edition's online chat feature. Access HP Instant Support Professional Edition at: <http://www.hp.com/go/ispe>.

Access the Business Support Center (BSC) at <http://www.hp.com/go/bizsupport> for the latest online support information, software and drivers, proactive notification, and worldwide community of peers and HP experts.

If it becomes necessary to call for technical assistance, be prepared to do the following tasks to ensure that your service call is handled properly:

- Be in front of your computer when you call.
- Before you call, write down the computer serial number and product ID number.

- Spend time troubleshooting the problem with the service technician.
- Remove any hardware that was recently added to your system.
- Remove any software that was recently installed.
- Restore the system from the Recovery Disc Set that you created or restore the system to its original factory condition in System Software Requirement Disks (SSRD).

 **IMPORTANT:** Restoring the system will erase all data on the hard drive. Be sure to back up all data files before running the restore process.

 **NOTE:** For sales information and warranty upgrades (Care Packs), call your local authorized service provider or dealer.

Helpful hints

If you encounter problems with the computer or software, see this list of general suggestions before taking further action.

- Check that the computer is plugged into a working electrical outlet.
- Check that the computer is turned on and the white power light is on.
- Check the power light on the front of the computer to see if it is blinking red. The blinking lights are error codes that help you diagnose the problem.
- Press and hold any key if the system beeps. Then the keyboard should be operating correctly.
- Check all cable connections for loose connections or incorrect connections.
- Wake the computer by pressing any key on the keyboard or pressing the power button. If the system remains in suspend mode, shut down the computer by pressing and holding the power button for at least four seconds, and then press the power button again to restart the computer. If the system will not shut down, unplug the power cord, wait a few seconds, and then plug it in again. The computer will restart if it is set to turn on automatically as soon as power is restored in Computer Setup. If it does not restart, press the power button to start the computer.
- Be sure that all the needed device drivers have been installed. For example, if you are using a printer, you need a driver for that model printer.
- Remove all bootable media (such as a USB device) from the system before turning it on.
- If you have installed an operating system other than the factory-installed operating system, check to be sure that it is supported on the system.

NOTICE: When the computer is plugged into an AC power source, there is always voltage applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

Solving general problems

You might be able to easily resolve the general problems described in this section. If a problem persists and you cannot resolve it yourself or if you feel uncomfortable about performing the operation, contact an authorized dealer or reseller.

⚠ CAUTION: When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock, hot surfaces, or both, be sure to disconnect the power cord from the AC outlet and allow the internal system components to cool before touching.

Cannot access the Computer Setup (F10) Utility when booting the computer

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| The Computer Setup (F10) Utility is set to Fast Boot causing the F10 access screen to display too briefly when booting the computer. | Before turning on the computer, press and hold F10 . Turn on the computer and continue to hold F10 until the Computer Setup (F10) Utility is displayed. - or - Follow the Windows® instructions for rebooting the computer into the Computer Setup (F10) Utility. |

Computer appears locked up and will not turn off when the power button is pressed

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Software control of the power switch is not functional. | <ol style="list-style-type: none">1. Press and hold the power button for at least 4 s until the computer turns off.2. Disconnect the power cord from the electrical outlet. |

Computer will not respond to keyboard or mouse

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Computer is in Sleep state. | To resume from Sleep state, press the power button. When attempting to resume from Sleep state, do not hold down the power button for more than 4 s. Otherwise, the computer shuts down and you lose any unsaved data. |
| System has locked up. | Restart computer. |
| USB cables may not be seated properly. | Disconnect, and then reconnect USB cables to keyboard and mouse. |

Computer date and time display is incorrect

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| RTC (real-time clock) battery may need to be replaced. | Reset the date and time under Control Panel . (Computer Setup can also be used to update the RTC date and time.) If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement. To access Control Panel in Windows 10, type <code>control panel</code> in the taskbar search box, and then select Control Panel. |

There is no sound or sound volume is too low

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| System volume might be set low or muted. | <ol style="list-style-type: none"> 1. Check the front panel to see if an amber light indicates the system has been muted. Tap the touch-sensitive button to toggle the mute on and off. 2. Check the Computer Setup settings to be sure that the internal system speaker is not muted. This setting does not affect the external speakers. 3. Be sure that the external speakers are properly connected and powered on and that the speakers' volume control is set correctly. 4. Use the system volume control available in the operating system to be sure that the speakers are not muted or to increase the volume. |

Cannot remove computer cover or access panel

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Smart Cover Lock, featured on some computers, is locked. | Unlock the Smart Cover Lock using Computer Setup. In case of forgotten password, power loss, or computer malfunction, you must manually disable the Smart Cover lock. A key to unlock the Smart Cover Lock is not available from HP. Keys are typically available from a hardware store. |

Poor performance

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Processor is too hot. | <ol style="list-style-type: none"> 1. Be sure that airflow to the computer is not blocked. Leave a 10.2 cm (4 inch) clearance on all vented sides of the computer to permit the required airflow. 2. Be sure that fans are connected and working properly (some fans only operate when needed). 3. Be sure that the processor heat sink is installed properly. |
| Hard drive is full. | Transfer data from the hard drive to create more space on the hard drive. |
| Low on memory. | Add more memory. |
| Hard drive fragmented. | Defragment hard drive. |
| Program previously accessed did not release reserved memory back to the system. | Restart the computer. |
| Virus resident on the hard drive. | Run virus protection program. |
| Too many applications running. | <ol style="list-style-type: none"> 1. Close unnecessary applications to free memory. 2. Add more memory. 3. Some applications run in the background and can be closed by right-clicking their corresponding icons in the task tray. |
| Some software applications, especially games, are stressful on the graphics subsystem. | <ol style="list-style-type: none"> 1. Lower the display resolution for the current application or consult the documentation that came with the application for suggestions on how to improve performance by adjusting parameters in the application. 2. Add more memory. 3. Upgrade the graphics solution. |
| Cause unknown. | Restart the computer. |

Computer powered off automatically and the power light blinks red four times and then white two times

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Processor thermal protection activated. A fan might be blocked or not turning, or the heat sink is not properly attached to the processor. | <ol style="list-style-type: none"> 1. Be sure that the computer air vents are not blocked and the processor cooling fan is running. 2. Open the access panel, press the power button, and see if the processor fan (or other system fan) spins. If the fan does not spin, be sure that the fan cable is plugged onto the system board header. 3. If fan is plugged in and not spinning, replace it. |

System does not turn on and the lights on the front of the computer are not blinking

Use this information to troubleshoot the computer.

| Cause | Solution |
|----------------------------|---|
| System unable to power on. | <p data-bbox="858 233 1422 281">Press and hold the power button for less than 4 s. If the hard drive light turns white, then:</p> <ol data-bbox="858 285 1437 516" style="list-style-type: none"><li data-bbox="858 285 1437 390">1. If the computer has a voltage selector, check that the voltage selector (located on the rear of the power supply) is set to the appropriate voltage. Proper voltage setting depends on your region.<li data-bbox="858 415 1417 464">2. Remove the expansion cards one at a time until the 5V_aux light on the system board turns on.<li data-bbox="858 489 1134 516">3. Replace the system board. <p data-bbox="906 541 930 562">OR</p> <p data-bbox="858 594 1422 642">Press and hold the power button for less than 4 s. If the hard drive light does not turn white, then:</p> <ol data-bbox="858 646 1437 1024" style="list-style-type: none"><li data-bbox="858 646 1409 674">1. Check whether the unit is plugged into a working AC outlet.<li data-bbox="858 699 1437 747">2. Open the access panel and check that the power button cable is properly connected to the system board.<li data-bbox="858 772 1437 821">3. Check that the power supply cables are properly connected to the system board.<li data-bbox="858 846 1437 894">4. Check to see if the 5V_aux light on the system board is turned on. If it is turned on, then replace the power button assembly.<li data-bbox="858 919 1437 968">5. If the 5V_aux light on the system board is off, then replace the power supply.<li data-bbox="858 993 1134 1020">6. Replace the system board. |

Solving power problems

These tables provide common causes and solutions for power problems.

Power supply shuts down intermittently

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| If the computer has a voltage selector, voltage selector switch on rear of computer chassis (some models) not switched to correct line voltage (115 V or 230 V). | Select the proper AC voltage using the selector switch. |
| Power supply will not turn on because of internal power supply fault. | Replace the power supply. |

Computer turned off automatically, power light blinks red two times followed by a two-second pause, and the computer beeps two times (Beeps stop after fifth iteration but lights continue blinking)

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Processor thermal protection activated. A fan might be blocked or not turning, or the heat sink is not properly attached to the processor. | <ol style="list-style-type: none">1. Be sure that the computer air vents are not blocked and the processor cooling fan is running.2. Open the access panel, press the power button, and see if the processor fan (or other system fan) spins. If the fan does not spin, be sure that the fan cable is plugged onto the system board header.3. If the fan is plugged in and not spinning, replace it. |

Power light blinks red four times followed by a two-second pause and the computer beeps four times (Beeps stop after fifth iteration but lights continue blinking)

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| Power failure (power supply is overloaded). | <ol style="list-style-type: none">1. If the computer has a voltage selector, check that the voltage selector, located on the rear of the power supply (some |

| Cause | Solution |
|-------|---|
| | <p>models), is set to the appropriate voltage. Proper voltage setting depends on your region.</p> <ol style="list-style-type: none"><li data-bbox="845 294 1404 357">2. Open the access panel, and be sure that the power supply cable is seated into the connector on the system board.<li data-bbox="845 378 1420 567">3. Check whether a device is causing the problem by removing all attached devices (such as hard drives or optical drives and expansion cards). Turn on the system. If the system enters POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly.<li data-bbox="845 588 1133 619">4. Replace the power supply.<li data-bbox="845 640 1133 672">5. Replace the system board. |

Solving hard drive problems

These tables provide common causes and solutions for hard drive problems.

Hard drive error occurs

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Hard disk has bad sectors or has failed. | <ol style="list-style-type: none">1. In Windows 10, type <code>file</code> in the taskbar search box, and then select File Explorer from the list of applications. In the left column, expand This PC, right-click a drive, select Properties, and then select the Tools tab. Under Error checking, click Check.2. Use a utility to locate and block usage of bad sectors. If necessary, reformat the hard disk. |

Disk transaction problem

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Either the directory structure is bad or there is a problem with a file. | In Windows 10, type <code>file</code> in the taskbar search box, and then select File Explorer from the list of applications. In the left column, expand This PC , right-click a drive, select Properties , and then select the Tools tab. Under Error checking , click Check . |

Drive not found (identified)

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Cable could be loose. | Check cable connections. |
| The system might not have automatically recognized a newly installed device. | See reconfiguration directions in the Solving hardware installation problems on page 64 section. If the system still does not recognize the new device, check to see if the device is listed in Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem. If this is a newly installed drive, run the Computer Setup utility, and add a POST delay under Advanced > Boot Options . |
| The device is attached to a SATA port that has been hidden in Computer Setup. | Run the Computer Setup utility and be sure that Device Available is selected for the device's SATA port in Advanced > Port Options . |
| Drive responds slowly immediately after startup. | Run Computer Setup and increase the POST Delay in Advanced > Boot Options . |

Nonsystem disk/NTLDR missing message

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| The system is trying to start from the hard drive, but the hard drive might have been damaged. | ▲ Perform Drive Protection System (DPS) testing in system ROM. |
| System files missing or not properly installed. | <ol style="list-style-type: none"> 1. Insert bootable media and restart the computer. 2. Boot to the windows installation media, and select the recovery option. If only a restore kit is available, then select the File Backup Program option, and then restore the system. 3. Install system files for the appropriate operating system. |
| Hard drive boot has been disabled in Computer Setup. | Run the Computer Setup utility, and enable the hard drive entry in the Advanced > Boot Options list. |
| Bootable hard drive is not attached as first in a multiple hard drive configuration. | If attempting to boot from a hard drive, be sure that it is attached to the system board dark blue SATA connector. |
| Bootable hard drive is not listed first in the Boot Order. | Run the Computer Setup utility, and select Advanced > Boot Options , and be sure that the bootable hard drive is listed immediately under the Hard Drive entry. |

Computer will not boot from hard drive

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| The device is attached to a SATA port that has been hidden in Computer Setup. | <ol style="list-style-type: none"> 1. Check SATA cable connections. 2. Run the Computer Setup utility, and be sure that Device Available is selected for the device's SATA port in Advanced > Port Options. |
| Boot order is not correct. | Run the Computer Setup utility, and change boot sequence in Advanced > Boot Options . |
| Hard drive is damaged. | Observe whether the front panel power light is blinking red and whether any beeps are heard. See the Worldwide Limited Warranty for terms and conditions. |

Computer seems to be locked up

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Program in use has stopped responding to commands. | <ol style="list-style-type: none"> 1. Use the task manager to close programs that do not respond. 2. Attempt the normal Windows shut down procedure. If this fails, press the power button for four or more seconds to turn off the power. To restart the computer, press the power button again. |

Solving audio problems

If the computer has audio features and you encounter audio problems, see the common causes and solutions listed in these tables.

Sound cuts in and out

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Processor resources are being used by other open applications. | Shut down all open processor-intensive applications. |

Sound does not come out of the speaker or headphones

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Software volume control is turned down or muted. | Double-click the Speaker icon on the taskbar, be sure that Mute is not selected, and use the volume slider to adjust the volume. You can perform this action with the touch-sensitive buttons on the front of the computer. |
| Audio is hidden in Computer Setup. | Enable the audio in Computer Setup: Advanced > Built-in Device Options . |
| The external speakers are not turned on. | Turn on the external speakers. |
| Headphones or devices connected to the line-out connector mute the internal speaker. | Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers. |
| Computer is in the Sleep state. | Press the power button to resume from the Sleep state. When attempting to resume from the Sleep state, do not hold down the power button for more than 4 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data. |
| Internal speaker is disabled in Computer Setup. | Enable the internal speaker in Computer Setup. Select Advanced > Built-in Device Options . |
| Some applications can select which audio output device is used. | Be sure that the application has selected the correct audio device. |
| The operating system controls might be set to use a different audio device as the default output device than what is expected. | Set the operating system to use the correct audio device. |

Computer appears to be locked up while recording audio

Use this information to troubleshoot the computer.

| Cause | Solution |
|------------------------------|---|
| The hard disk might be full. | Before recording, be sure that there is enough free space on the hard disk. You can also try recording the audio file in a compressed format. |

Line-in jack is not functioning properly

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| Jack has been reconfigured in the audio driver or application software. | In the audio driver or application software, reconfigure the jack or set the jack to its default value. |

Solving printer problems

If you encounter printer problems, see the documentation that came with the printer and the common causes and solutions listed in these tables.

Printer will not print

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Printer is not turned on and online. | Turn the printer on and be sure that it is online. |
| The correct printer drivers for the application are not installed. | <ol style="list-style-type: none">1. Install the correct printer driver for the application.2. Try printing using the MS-DOS command: DIR C:\ > [printer port] where [printer port] is the address of the printer being used. If the printer works, reload the printer driver. To run MS-DOS commands, press the Windows key + r, type <code>cmd</code> in the Open box, and then select OK. |
| If you are on a network, you might not have made the connection to the printer. | Make the proper network connections to the printer. |
| Printer might have failed. | Run printer self-test. |

Printer will not turn on

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| The cables might not be connected properly. | Reconnect all cables, and check the power cord and electrical outlet. |

Printer prints garbled information

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| The correct printer driver for the application is not installed. | Install the correct printer driver for the application. |
| The cables might not be connected properly. | Reconnect all cables. |
| Printer memory might be overloaded. | Reset the printer by turning it off for 1 min, and then turn it back on. |

Printer will not print

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Printer is not turned on and online. | Turn the printer on and be sure that it is online. |
| The correct printer drivers for the application are not installed. | <ol style="list-style-type: none">1. Install the correct printer driver for the application.2. Try printing using the MS-DOS command: DIR C:\ > [printer port] where [printer port] is the address of the printer being used. If the printer works, reload the printer driver. To run MS-DOS commands, press the Windows key + r, type cmd in the Open box, and then select OK. |
| If you are on a network, you might not have made the connection to the printer. | Make the proper network connections to the printer. |
| Printer might have failed. | Run printer self-test. |

Solving keyboard and mouse problems

If you encounter keyboard or mouse problems, see the documentation that came with the equipment and the common causes and solutions listed in these tables.

Keyboard commands and typing are not recognized by the computer

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Keyboard connector is not properly connected. | Shut down the computer, reconnect the keyboard, and then restart the computer. |
| Program in use has stopped responding to commands. | Shut down your computer using the mouse, and then restart the computer. |
| Keyboard needs repairs. | See the Worldwide Limited Warranty for terms and conditions. |
| Computer is in the Sleep state. | Press the power button to resume from the Sleep state. When attempting to resume from the Sleep state, do not hold down the power button for more than 4 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data. |

Mouse does not respond to movement or is too slow

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| Mouse connector is not properly plugged into the back of the computer. | Shut down the computer using the keyboard. <ol style="list-style-type: none">1. Press the ctrl and esc keys at the same time (or press the Windows logo key) to display the Start menu.2. Use the arrow keys to scroll to and select the power icon at the top right on the menu, and then press enter.3. Use the arrow keys to select Shut Down, and then press enter.4. After the shutdown is complete, plug the mouse connector into the back of the computer (or the keyboard) and restart. |
| Program in use has stopped responding to commands. | Shut down the computer using the keyboard, and then restart the computer. |
| Mouse might need repair. | See the Worldwide Limited Warranty for terms and conditions. |
| Computer is in the Sleep state. | Press the power button to resume from the Sleep state. When attempting to resume from the Sleep state, do not hold down the power button for more than 4 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data. |
| If using a wireless mouse, you might need to resynchronize the mouse with the computer. | Follow the instructions that came with the mouse. |

Solving hardware installation problems

You might need to reconfigure the computer when you add or remove hardware, such as an additional drive or expansion card.

If you install a plug and play device, Windows automatically recognizes the device and configures the computer. If you install a non-plug and play device, you must reconfigure the computer after completing installation of the new hardware. In Windows, use the **Add Hardware Wizard**, and follow the instructions that appear on the screen.

To open the Add Hardware Wizard, open a command prompt and type .

⚠ WARNING! When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock, hot surfaces, or both, be sure to disconnect the power cord from the AC outlet and allow the internal system components to cool before touching.

A new device is not recognized as part of the system

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Cables of new external device are loose or power cables are unplugged. | Be sure that all cables are properly and securely connected and that pins in the cable or connector are not bent down. |
| Power switch of new external device is not turned on. | Turn off the computer, turn on the external device, and then turn on the computer to integrate the device with the computer system. |
| When the system advised you of changes to the configuration, you did not accept them. | Reboot the computer and follow the instructions for accepting the changes. |
| A plug and play board might not automatically configure when added if the default configuration conflicts with other devices. | Use Windows Device Manager to clear the automatic settings for the board, and choose a basic configuration that does not cause a resource conflict. You can also use Computer Setup to reconfigure or disable devices to resolve the resource conflict. To access Device Manager in Windows 10, type <code>device manager</code> in the taskbar search box, and then select Device Manager from the list of applications. |
| USB ports on the computer are disabled in Computer Setup. | Run the Computer Setup utility and ensure that Device available is selected for appropriate USB ports under Advanced > Port Options . |

Computer will not start

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Wrong memory modules were used in the upgrade, or memory modules were installed in the wrong location. | <ol style="list-style-type: none">1. Review the documentation that came with the system to determine if you are using the correct memory modules and to verify the proper installation. NOTE: DIMM1 or XMM1 must always be installed. DIMM1 must be installed before DIMM3.2. Observe the beeps and lights on the front of the computer. Beeps and blinking lights are codes for specific problems.3. If you still cannot resolve the issue, contact Customer Support. |

Power light blinks red three times and then white two times

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Memory is installed incorrectly or is bad. | <p>To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a DIMM module.</p> <ol style="list-style-type: none">1. Reseat DIMMs. Turn on the system.2. Replace DIMMs one at a time to isolate the faulty module. <p>NOTE: DIMM1 or XMM1 must always be installed. DIMM1 must be installed before DIMM3.</p> <ol style="list-style-type: none">3. Replace third-party memory with HP memory.4. Replace the system board. |

Solving network problems

Some common causes and solutions for network problems are listed in these tables. The guidelines do not discuss the process of debugging the network cabling.

Network driver does not detect network controller

Use this information to troubleshoot the computer.

| Cause | Solution |
|---------------------------------|---|
| Network controller is disabled. | <ol style="list-style-type: none">1. Run Computer Setup and enable network controller.2. Enable the network controller in the operating system using Device Manager. To access Device Manager in Windows 10, type <code>device manager</code> in the taskbar search box, and then select Device Manager from the list of applications. |
| Incorrect network driver. | Check the network controller documentation for the correct driver or obtain the latest driver from the manufacturer's website. |

Network status link light never blinks

Use this information to troubleshoot the computer.



NOTE: The network status light is supposed to blink when there is network activity.

| Cause | Solution |
|--|---|
| No active network is detected. | Check cabling and network equipment for proper connection. |
| Network controller is not set up properly. | Check for the device status within Windows, such as Device Manager for driver load and the Network Connections applet within Windows for link status. To access Device Manager in Windows 10, type <code>device manager</code> in the taskbar search box, and then select Device Manager from the list of applications. |
| Network controller is disabled. | <ol style="list-style-type: none">1. Run Computer Setup and enable network controller.2. Enable the network controller in the operating system using Device Manager. To access Device Manager in Windows 10, type <code>device manager</code> in the taskbar search box, and then select Device Manager from the list of applications. |
| Network driver is not properly loaded. | Reinstall network drivers. |
| System cannot autosense the network. | Disable autosensing capabilities, and force the system into the correct operating mode. |

Diagnostics reports a failure

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| The cable is not securely connected. | Be sure that the cable is securely attached to the network connector and that the other end of the cable is securely attached to the correct device. |
| The cable is attached to the incorrect connector. | Be sure that the cable is attached to the correct connector. |
| There is a problem with the cable or a device at the other end of the cable. | Be sure that the cable and device at the other end are operating correctly. |
| The network controller is defective. | Contact an authorized service provider. |

Diagnostics passes, but the computer does not communicate with the network

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Network drivers are not loaded, or driver parameters do not match current configuration. | Be sure that the network drivers are loaded and that the driver parameters match the configuration of the network controller. Be sure that the correct network client and protocol is installed. |
| The network controller is not configured for this computer. | Select the Network and Sharing Center icon in the Control Panel , and configure the network controller. To access Control Panel in Windows 10, type <code>control panel</code> in the taskbar search box, and then select Control Panel from the list of applications. |

Network controller stopped working when an expansion board was added to the computer

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| The network controller requires drivers. | Verify that the drivers were not accidentally deleted when the drivers for a new expansion board were installed. |

Network controller stops working without apparent cause

Use this information to troubleshoot the computer.

| Cause | Solution |
|--------------------------------------|---|
| The cable is not securely connected. | Be sure that the cable is securely attached to the network connector, and that the other end of the cable is securely attached to the correct device. |
| The network controller is defective. | Contact an authorized service provider. |

Cannot connect to network server when attempting remote system installation

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| The network controller is not configured properly. | Verify network connectivity, that a DHCP Server is present, and that the Remote System Installation Server contains the network interface card (NIC) drivers for your NIC. |

System setup utility reports unprogrammed EEPROM

Use this information to troubleshoot the computer.

| Cause | Solution |
|----------------------|---|
| Unprogrammed EEPROM. | Contact an authorized service provider. |

Solving memory problems

If you encounter memory problems, some common causes and solutions are listed in these tables.

 **IMPORTANT:** Power can still be supplied to the DIMMs when the computer is turned off (depending on the Management Engine (ME) settings). To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a memory module.

For those systems that support ECC memory, HP does not support mixing ECC and non-ECC memory. Otherwise, the computer will not boot the operating system.

 **NOTE:** The memory count will be affected by configurations with the Management Engine (ME) enabled. The ME uses 8 MB of system memory in single-channel mode or 16 MB of memory in dual-channel mode to download, decompress, and execute the ME firmware for Out-of-Band (OOB), third-party data storage, and other management functions.

System will not boot or does not function properly after installing additional memory modules

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| A memory module is not installed in the DIMM1 or XMM1 socket. | Verify that a memory module is installed in the DIMM1 or XMM1 socket on the system board. This socket must be populated with a memory module. |
| Memory module is not the correct type or speed grade for the system, or the new memory module is not seated properly. | Replace module with the correct industry-standard device for the computer. On some models, ECC and non-ECC memory modules cannot be mixed. |

Out of memory error

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| You have run out of memory to run the application. | Check the application documentation to determine the memory requirements. |

Memory count during POST is wrong

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| The memory modules might not be installed correctly. | Check that the memory modules have been installed correctly and that proper modules are used. |
| Integrated graphics might use system memory. | No action required. |

Insufficient memory error during operation.

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|---|
| Too many Terminate and Stay Resident programs (TSRs) are installed. | Delete any TSRs that you do not need. |
| You have run out of memory for the application. | Check the memory requirements for the application or add more memory to the computer. |

Power light blinks red five times followed by a two-second pause and the computer beeps five times (Beeps stop after fifth iteration but lights continue blinking)

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| Memory is installed incorrectly or is bad. | <ol style="list-style-type: none">1. Reseat DIMMs. Turn on the system.2. Replace DIMMs one at a time to isolate the faulty module.3. Replace third-party memory with HP memory.4. Replace the system board. |

Solving USB flash drive problems

If you encounter USB flash drive problems, common causes and solutions are listed in these tables.

USB flash drive is not seen as a drive letter in Windows

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| The drive letter after the last physical drive is not available. | Change the default drive letter for the flash drive in Windows. |

USB flash drive not found (identified)

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| The device is attached to a USB port that has been hidden in Computer Setup. | Run the Computer Setup utility and enable USB ports in Advanced > Port Options . |
| The device was not properly seated before startup. | Be sure that the device is fully inserted into the USB port before applying power to the system |

System will not boot from USB flash drive

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Boot order is not correct. | Run the Computer Setup utility, and change boot sequence in Advanced > Boot Options . |
| Removable Media Boot is disabled in the Computer Setup utility. | Run the Computer Setup utility, and enable booting to removable media in Advanced > Boot Options . Be sure that USB is enabled in Storage > Boot Order . |

The computer boots to DOS after making a bootable flash drive

Use this information to troubleshoot the computer.

| Cause | Solution |
|---------------------------|--|
| Flash drive is bootable. | Install the flash drive only after the operating system boots. |
| Flash drive is defective. | Try a different flash drive. |

Solving internet access problems

If you encounter internet access problems, consult your internet service provider (ISP), or see the common causes and solutions listed in these tables.

Unable to connect to the internet

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|---|
| Internet Service Provider (ISP) account is not set up properly. | Verify Internet settings, or contact your ISP for assistance. |
| Web browser is not set up properly. | Verify that the web browser is installed, and set up to work with your ISP. |
| Cable/DSL modem is not plugged in. | Plug in cable/DSL modem. You should see a power light on the front of the cable/DSL modem. |
| Cable/DSL service is not available or has been interrupted due to bad weather. | Try connecting to the internet at a later time or contact your ISP. (If the cable/DSL service is connected, the cable light on the front of the cable/DSL modem will be on.) |
| The CAT5 UTP cable is disconnected. | Connect the CAT5 UTP cable between the cable modem and the computer's RJ-45 connector. (If the connection is good, the PC light on the front of the cable/DSL modem will be on.) |
| IP address is not configured properly. | Contact your ISP for the correct IP address. |
| Cookies are corrupted. (A "cookie" is a small piece of information that a web server can store temporarily with the web browser. This is useful for having the browser remember some specific information that the Web server can later retrieve.) | <ol style="list-style-type: none">1. Type <code>control panel</code> in the taskbar search box, and then select Control Panel from the list of applications.2. Click Internet Options.3. In the Browsing history section, click the Delete button.4. Select the Cookies and website data check box, and click the Delete button. |

Cannot automatically launch internet programs

Use this information to troubleshoot the computer.

| Cause | Solution |
|--|--|
| You must log on to your ISP before some programs will start. | Log on to your ISP and launch the program. |

Solving software problems

Most software problems occur as a result of these situations.

- The application was not installed or configured correctly.
- There is insufficient memory available to run the application.
- There is a conflict between applications.
- All the necessary device drivers might not have been installed.
- If you have installed an operating system other than the factory-installed operating system, it might not be supported on the system.

If you encounter software problems, see the applicable solutions listed in the following table.

Computer will not start up and the HP logo does not appear

Use this information to troubleshoot the computer.

| Cause | Solution |
|--------------------------------------|---|
| ROM issue - POST error has occurred. | Observe the beeps and lights on the front of the computer. See the Worldwide Limited Warranty for terms and conditions. |

“Illegal Operation has Occurred” error message is displayed

Use this information to troubleshoot the computer.

| Cause | Solution |
|---|--|
| Software being used is not Microsoft-certified for your version of Windows. | Verify that the software is certified by Microsoft for your version of Windows (see program packaging for this information). |
| Configuration files are corrupt. | If possible, save all data, close all programs, and restart the computer. |

6 Computer Setup (F10) Utility

This information provides details of the Computer Setup Utility.

- Change settings from the defaults or restore the settings to default values.
- View the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of bootable devices such as hard drives or USB flash media devices.
- Enter the Asset Tag or property identification number assigned by the company to this computer.
- Enable the power-on password prompt during system restarts (warm boots) as well as during startup.
- Establish an administrator password that controls access to the Computer Setup (F10) Utility and the settings described in this section.
- Establish minimum requirements for valid passwords, including length and required types of characters.
- Secure integrated I/O functionality, including the serial, USB, or audio, or embedded NIC, so that they cannot be used until they are unsecured.
- Enable or disable different types of boot sources.
- Configure features such as Secure Boot, power management, virtualization support, and language and keyboard type used in Setup and POST.
- Replicate the system setup by saving system configuration information about a USB device and restoring it on one or more computers.
- Enable or disable DriveLock security or securely erase a hard drive (when supported by drive).

Using Computer Setup (F10) Utilities

You can access Computer Setup only by turning the computer on or restarting the system.

To access the Computer Setup Utilities menu, complete these steps:

1. Turn on or restart the computer.
2. Repeatedly press **f10** when the power button light turns white to access the utility.

You can also press **esc** to see a menu that allows you to access different options available at startup, including the Computer Setup utility.

A choice of four headings appears in the Computer Setup Utilities menu: Main, Security, Advanced, and UEFI Drivers.

 **NOTE:** If you do not press **f10** at the appropriate time, you must restart the computer and again repeatedly press **f10** when the power button light turns white to access the utility.

 **NOTE:** Selecting UEFI Drivers restarts the computer into the third-party option ROM management application. You can access this application directly by pressing **f3** during startup.

3. Use the arrow (left and right) keys to select the appropriate heading. Use the arrow (up and down) keys to select the option you want, and then press **enter**. To return to the Computer Setup Utilities menu, press **esc**.
4. To apply and save changes, select **Main > Save Changes and Exit**.
 - If you have made changes that you do not want applied, select **Ignore Changes and Exit**.
 - To restore settings from the Advanced and Main menus to original values, select **Apply Factory Defaults and Exit**.
 - To restore settings from the Advanced and Main menus to those previously saved by **Save Custom Defaults**, select **Apply Custom Defaults and Exit**. If no custom defaults have been saved, then factory defaults are used.

 **NOTE:** You cannot modify settings in the Security menu by selecting **Apply Defaults**. You reset those values by selecting **Restore Security Settings to Factory Defaults** at the bottom of the **Security** menu.

 **NOTE:** Not all settings shown in the following sections are available for all models.

 **IMPORTANT:** Do not turn computer power off while the BIOS is saving the Computer Setup (F10) changes because the settings could become corrupted. It is safe to turn off the computer only after exiting the F10 Setup screen.

Computer Setup—Main

This table provides information about the Computer Setup Main menu.

 **NOTE:** Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-1 Computer Setup—Main

| Option | Description |
|---------------------------|--|
| System Information | Lists all information in following list if Advanced System Information is selected. Lists smaller subset if Basic System Information is selected. <ul data-bbox="531 338 919 1734" style="list-style-type: none"><li data-bbox="531 338 703 359">• Product name<li data-bbox="531 390 767 411">• Installed memory size<li data-bbox="531 443 708 464">• Processor type<li data-bbox="531 495 852 516">• Processor cache size (L1/L2/L3)<li data-bbox="531 548 724 569">• Processor speed<li data-bbox="531 600 740 621">• MicroCode revision<li data-bbox="531 653 743 674">• Processor stepping<li data-bbox="531 705 708 726">• Memory speed<li data-bbox="531 758 895 779">• DIMM size (for each installed module)<li data-bbox="531 810 756 831">• System BIOS version<li data-bbox="531 863 852 884">• ME Firmware version (Intel only)<li data-bbox="531 915 740 936">• Video BIOS version<li data-bbox="531 968 783 989">• Reference code revision<li data-bbox="531 1020 807 1041">• Super I/O firmware version<li data-bbox="531 1073 919 1094">• USB Type-C controller firmware version<li data-bbox="531 1125 692 1146">• Born on date<li data-bbox="531 1178 700 1199">• Serial number<li data-bbox="531 1230 687 1251">• SKU number<li data-bbox="531 1283 879 1304">• UUID (Universally Unique Identifier)<li data-bbox="531 1335 772 1356">• Asset tracking number<li data-bbox="531 1388 692 1409">• Feature byte<li data-bbox="531 1440 644 1461">• Build ID<li data-bbox="531 1493 708 1514">• Product family<li data-bbox="531 1545 724 1566">• System board ID<li data-bbox="531 1598 799 1619">• System board CT number<li data-bbox="531 1650 671 1671">• Panel type<li data-bbox="531 1703 751 1724">• Panel serial number<li data-bbox="531 1755 783 1776">• Integrated MAC Address |

Table 6-1 Computer Setup—Main (continued)

| Option | Description |
|---------------------------|---|
| System Diagnostics | <p>If the hard drive has the HP Advanced Diagnostics installed, the application launches. If HP Advanced Diagnostics is not installed, then a basic version that is built into the BIOS provides the capability to perform the following functions:</p> <ul style="list-style-type: none"> • Memory Test • Hard Drive Check • Language |
| Update System BIOS | <p>Lets you update the system BIOS from www.hp.com or another network server, from a removable USB drive, or from a file located on the hard drive.</p> <ul style="list-style-type: none"> • Check [current selection] for BIOS Updates <ul style="list-style-type: none"> The string that appears here depends on the setting in BIOS Update Preferences. • Lock BIOS Version <ul style="list-style-type: none"> If this option is selected, the system is locked to the current BIOS version and, updates are not allowed. • BIOS Rollback Policy <ul style="list-style-type: none"> ■ Unrestricted Rollback to older BIOS—Lets you roll back to any previous version of BIOS. ■ Restricted Rollback to older BIOS—If selected, Minimum BIOS Version becomes active, which lets you manually enter the minimum BIOS version that you can roll back to. • Allow BIOS Updates Using a Network • BIOS Update Preferences <ul style="list-style-type: none"> ■ Check for Update on Next Reboot—Default is disabled. ■ BIOS Source—Lets you select either HP.com or a custom URL. If Custom URL is selected, Edit Custom URL becomes active. HP recommends using a custom URL only for a managed IT environment. ■ Automatic BIOS Update Setting <ul style="list-style-type: none"> Allows configuration of a periodic check for updates: NOTE: If Microsoft Windows BitLocker Drive Encryption (BDE) is enabled, it must be temporarily suspended before the BIOS is flashed. ■ Do not update ■ Checking for updates and prompt the user to accept or reject the update at that time ■ Checking for updates and install all new versions ■ Checking for updates and install only new versions marked important ■ BIOS Update Frequency |

Table 6-1 Computer Setup—Main (continued)

| Option | Description |
|--|---|
| | <ul style="list-style-type: none">■ Daily■ Weekly■ Monthly (default) <ul style="list-style-type: none">● Network Configuration Settings● Update BIOS Using Local Media <p>Lets you access files on either USB storage or the hard drive. The HP BIOS Update and Recovery application included in BIOS Softpaqs at www.hp.com copies the BIOS file to the correct location on the hard drive or USB device.</p> |
| Change date and time | Lets you update system date and time. |
| Set machine unique data | Allows you to set or view data that is unique to each machine, such as feature byte, build ID, serial number, SKU number, product family, system board CT number, and product name. |
| System IDs | Lets you set the following values: <ul style="list-style-type: none">● Asset Tracking Number● Ownership Tag |
| Replicated Setup | <p>Backup current settings to USB device</p> <p>Saves system configuration to a formatted USB flash media device.</p> <p>Restore current settings from USB device</p> <p>Restores system configuration from a USB flash media device.</p> |
| Save Custom Defaults | Saves the current system configuration settings as the custom default set. |
| Apply Custom Defaults and Exit | Applies the custom default settings to the computer after rebooting. Does not apply to options in the Security menu. |
| Apply Factory Defaults and Exit | Restores the factory system configuration settings to the computer after rebooting. Does not apply to options in the Security menu. |
| Ignore Changes and Exit | Exits Computer Setup without applying or saving any changes. |
| Save Changes and Exit | Saves changes to current system configuration, exits Computer Setup, and reboots. |
| Suppress POST errors | Select to turn off any errors generated by Power On Self Test (POST) during boot up. |

Computer Setup—Security

This table provides information about the Computer Setup Security menu.



NOTE: Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-2 Computer Setup—Security

| Option | Description |
|--|--|
| Create BIOS Administrator Password | <p>Lets you set and enable a BIOS administrator password, which controls access to the following features:</p> <ul style="list-style-type: none"> • Setup Menu (F10) • Third Party Option ROM Management (F3) • Update system ROM • WMI commands that change system settings • BIOS Configuration Utility (BCU) • Alternative power-on password <p>NOTE: Creating a BIOS user disables the Fast Boot option.</p> <p>NOTE: If the password is set, you must change Computer Setup options, update the BIOS, and make changes to certain plug and play settings under Windows.</p> |
| Change BIOS Administrator Password (This selection is active only if a BIOS administrator password is set.) | <p>Lets you change the BIOS administrator password.</p> <p>You must know the current password to be able to change it.</p> |
| Create POST Power-On Password | <p>The power-on password prompt appears after a power cycle or reboot. If the user does not enter the correct power-on password, the unit will not boot.</p> |
| Change POST Power-On Password (This selection is active only if a BIOS administrator password is set.) | <p>Lets you change the POST power-on password.</p> <p>You must know the current password to be able to change it.</p> |
| Password Policies | <p>Let you set the guidelines for a valid password. Options include:</p> <ul style="list-style-type: none"> • Password minimum length • Requires at least one symbol • Requires at least one number • Requires at least one uppercase character • Requires at least one lowercase character • Allow spaces <p>Clear Password Jumper</p> <p>Select Honor to allow or Ignore to not allow the absence of the password jumper to clear the passwords at boot up. Default is Honor.</p> |
| Security Configuration | <p>TPM Embedded Security</p> <ul style="list-style-type: none"> • TPM Specification Version |

Table 6-2 Computer Setup—Security (continued)

| Option | Description |
|--------|---|
| | Displays the current TPM version. |
| | <ul style="list-style-type: none"> • TPM Device Lets you set the Trusted Platform Module as available or hidden. • TPM State Select to enable the TPM. • ClearTPM Select to reset the TPM to an unowned state. After the TPM is cleared, it is also turned off. To temporarily suspend TPM operations, turn the TPM off instead of clearing it. IMPORTANT: Clearing the TPM resets it to factory defaults and turns it off. You will lose all created keys and data protected by those keys. • TPM Activation Policy <ul style="list-style-type: none"> ○ F1 to boot ○ Allow user to reject ○ No prompts |
| | BIOS SureStart |
| | <ul style="list-style-type: none"> • Verify Boot Block on every boot—Select to enable HP SureStart. • BIOS Data Recovery Policy—Select Automatic or Manual to determine data recovery process. Manual recovery is intended only for situations when you want forensic analysis before HP SureStart recovery. When this policy is set to manual, HP SureStart will not correct any issues that are found until the local user enters the manual recovery key sequence. This can result in a computer that cannot boot until the manual recovery key sequence is entered. • Dynamic Runtime Scanning of Boot Block—Verifies the integrity of the BIOS boot block region several times each hour while the computer is running. Default is Enabled. • Sure Start BIOS Settings Protection—When enabled, HP Sure Start locks all critical BIOS settings and provides enhanced protection for these settings using nonvolatile (flash) memory. NOTE: An administrator password must be set to activate this setting. • Enhanced HP Firmware Runtime Intrusion Prevention and Detection—Enables monitoring of HP system firmware executing out of main memory while the operating system is running. Any anomalies detected in HP system firmware that is active while the operating system is running will result in a Sure Start security event being generated. • Sure Start Security Event Policy—Controls HP Sure Start behavior upon identifying a critical security event (any modification to HP firmware) while the operating system is running. <ul style="list-style-type: none"> – Log Event Only—HP Sure Start will log all critical security events in the HP Sure Start audio log within the HP Sure Start nonvolatile (flash) memory. – Log Event and notify user—In addition to logging all critical security events, HP Sure Start will notify the user within the operating system that a critical event has occurred. – Log Event and power off system—In addition to logging all critical security events, HP Sure Start turns of the computer upon detecting a HP Sure Start Security Event. Because of the potential for |

Table 6-2 Computer Setup—Security (continued)

| Option | Description |
|------------------|---|
| | <p data-bbox="603 260 1433 310">data loss, HP recommends this setting only in situations where security integrity of the system is a higher priority than the risk of potential data loss.</p> <p data-bbox="507 338 612 363">Smart Cover</p> <ul data-bbox="507 390 1150 415" style="list-style-type: none"> <li data-bbox="507 390 1150 415">• Cover Removal Sensor (Disabled/Notify user/Administrator password) <p data-bbox="507 443 1437 493">Lets you disable the cover sensor or configure what action is taken if the computer cover is removed. Default is Disabled.</p> <p data-bbox="507 520 1426 594">NOTE: Notify user alerts the user with a POST error on the first boot after the sensor detects removal of the cover. If the password is set, Administrator Password requires that the password be entered to boot the computer if the sensor detects that the cover has been removed.</p> <p data-bbox="507 621 834 646">Intel Software Guard Extensions (SGX)</p> <p data-bbox="507 674 1433 747">Intel SGX is a set of processor code instructions from that allows user-level code to allocate private regions of memory, that unlike normal process memory is also protected from processes running at higher privilege levels.</p> <ul data-bbox="507 774 699 898" style="list-style-type: none"> <li data-bbox="507 774 699 800">• Software control <li data-bbox="507 827 619 852">• Disable <li data-bbox="507 879 619 905">• Enable |
| Utilities | <p data-bbox="507 926 667 951">Hard Drive Utilities</p> <ul data-bbox="507 978 900 1003" style="list-style-type: none"> <li data-bbox="507 978 900 1003">• Save/Restore MBR of System Hard Drive <p data-bbox="555 1031 1401 1081">NOTE: Windows 10 systems are generally not formatted to include an Master Boot Record (MBR). Instead they use GUID Partition Table (GPT) format, which better supports large hard drives.</p> <p data-bbox="555 1108 1433 1159">Enabling this feature will save the MBR of the system hard drive. If the MBR gets changed, the user will be prompted to restore the MBR. Default is disabled.</p> <p data-bbox="555 1186 1433 1310">The MBR contains information needed to successfully boot from a disk and to access the data stored on the disk. Master Boot Record Security can prevent unintentional or malicious changes to the MBR, such as those caused by some viruses or by the incorrect use of certain disk utilities. It also allows you to recover the "last known good" MBR, should changes to the MBR be detected when the system is restarted.</p> <p data-bbox="555 1337 1385 1388">NOTE: Most operating systems control access to the MBR of the current bootable disk; the BIOS cannot prevent changes that may occur while the operating system is running.</p> <p data-bbox="555 1415 1321 1440">Restores the backup Master Boot Record to the current bootable disk. Default is disabled.</p> <p data-bbox="555 1467 1018 1493">Only appears if all of the following conditions are true:</p> <ul data-bbox="555 1520 1310 1644" style="list-style-type: none"> <li data-bbox="555 1520 810 1545">– MBR security is enabled. <li data-bbox="555 1572 1059 1598">– A backup copy of the MBR has been previously saved. <li data-bbox="555 1625 1310 1650">– The current bootable disk is the same disk from which the backup copy was saved. |

Table 6-2 Computer Setup—Security (continued)

| Option | Description |
|---|--|
| | <p>IMPORTANT: If you restoring a previously saved MBR after a disk utility or operating system modified the MBR, the data on the disk might become inaccessible. Only restore a previously saved MBR if you are confident that the current bootable disk's MBR has been corrupted or infected with a virus.</p> <ul style="list-style-type: none"> Save/Restore GPT of System Hard Drive Enabling this feature saves the GUID Partition Table (GPT) of the system hard drive. If the GPT is subsequently changed, the user is prompted to choose whether to restore GPT. DriveLock/Automatic DriveLock Allows you to assign or modify a master or user password for hard drives. When this feature is enabled, the user is prompted to provide one of the DriveLock passwords during POST. If neither is successfully entered, the hard drive remains inaccessible until one of the passwords is successfully provided during a subsequent cold-boot sequence. <p>NOTE: This selection appears only when at least one drive that supports the DriveLock feature is attached to the system.</p> <p>IMPORTANT: Be aware that these settings take place immediately. It is not necessary to save.</p> <p>IMPORTANT: Be sure to document the DriveLock password. Losing a DriveLock password will render a drive permanently locked.</p> After you select a drive, the following options are available: - Set DriveLock Master Password. Sets the drive's master password but does not enable DriveLock. - Enable DriveLock. Sets the drive's user password and enables DriveLock. Secure Erase Lets you select a hard drive to completely erase. After you erase a hard drive with a program that uses Secure Erase firmware commands, no file recovery program, partition recovery program, or other data recovery method can extract data from the drive. Allow OPAL Hard Drive SED Authentication Default is disabled. |
| System Management Command | Allows authorized personnel to reset security settings during a service event. Default is enabled. |
| Restore Security Settings to Default | This action resets security devices, clears BIOS passwords (not including DriveLock), and restores settings in the Security menu to factory defaults. |

Computer Setup—Advanced

This table provides information about the Computer Setup Advanced menu.

 **NOTE:** Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-3 Computer Setup—Advanced (for advanced users)

| Option | Heading |
|-------------------------|---|
| Display Language | Lets you select the language of the menus in F10 Setup and the keyboard layout. |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|--------------------|--|
| Scheduled Power-On | This feature wakes the system when it is off at a specified date and time. |
| Boot Options | <p>Select the devices that the computer can boot from, as well as other options, including:</p> <ul style="list-style-type: none"> • Startup Delay (sec). Enabling this feature adds a user-specified delay to the POST process. One purpose for the delay is to provide additional time to activate hotkeys such as esc for the Startup Menu or f10 for Computer Setup. • Fast Boot—Default is enabled. • USB Storage Boot—Default is enabled. • Network (PXE) Boot—Default is enabled. • After Power Loss—Default is Power Off. <ul style="list-style-type: none"> ■ Power off—Causes the computer to remain off when power is restored. ■ Power on—Causes the computer to turn on automatically as soon as power is restored. ■ Previous state—Causes the computer to turn on automatically as soon as power is restored, if it was on when power was lost. <p>NOTE: If the system is configured to Power On from Keyboard Ports (see Power Management Options), then this setting is forced to Power On.</p> <ul style="list-style-type: none"> • Prompt on Memory Size Change. Default is enabled. • Prompt on Fixed Storage Change. Default is disabled. • Audio Alerts During Boot. Default is enabled. When disabled, most audible beeps from errors, warnings, and password prompts during boot up are suppressed. • UEFI Boot Order. <p>Default is enabled. Specify the order in which UEFI boot sources (such as a internal hard drive, USB hard drive, USB optical drive, or internal optical drive) are checked for a bootable operating system image.</p> <p>UEFI boot sources always have precedence over legacy boot sources.</p> • Legacy Boot Order <p>Specify the order in which legacy boot sources (such as a network interface card, internal hard drive, USB optical drive, or internal optical drive) are checked for a bootable operating system image.</p> <p>Specify the order of attached hard drives. The first hard drive in the order will have priority in the boot sequence and will be recognized as drive C (if any devices are attached).</p> <p>NOTE: To drag a device to a preferred place, press enter.</p> <p>NOTE: MS-DOS drive lettering assignments might not apply after a non-MS-DOS operating system has started.</p> <p>Shortcut to Temporarily Override Boot Order</p> <p>To boot one time from a device other than the default device specified in Boot Order, restart the computer and press esc (to access the Startup menu) and then f9 (Boot Menu), or only f9 (skipping the Startup menu) when the power button light turns white. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press enter. The computer then boots from the selected non-default device for this one time.</p> |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|---------------------------|--|
| Secure Boot Configuration | Configure Legacy Support and Secure Boot <p data-bbox="531 312 1410 363">Lets you turn off all legacy support on the computer, including booting to DOS, running legacy graphics cards, booting to legacy devices, and so on.</p> <p data-bbox="531 392 1458 491">Lets you be sure that an operating system is legitimate before booting to it, making Windows resistant to malicious modification from preboot to full operating system booting, preventing firmware attacks. UEFI and Windows Secure Boot only allow code signed by preapproved digital certificates to run during the firmware and OS boot process.</p> <ul data-bbox="531 520 991 646" style="list-style-type: none"><li data-bbox="531 520 991 541">• Legacy Support Enable and Secure Boot Disable<li data-bbox="531 571 991 592">• Legacy Support Disable and Secure Boot Enable<li data-bbox="531 621 991 642">• Legacy Support Disable and Secure Boot Disable <p data-bbox="531 672 1035 693">Default is Legacy Support Disable and Secure Boot Disable.</p> Secure Boot Key Management <p data-bbox="531 772 893 793">Lets you manage the custom key settings.</p> Import Custom Secure Boot keys <p data-bbox="531 873 692 894">Default is disabled.</p> Clear Secure Boot Keys <p data-bbox="531 974 1430 1024">Lets you delete any previously loaded custom boot keys. Clearing keys will disable secure boot. Default is disabled.</p> Reset Secure Boot keys to factory defaults <p data-bbox="531 1104 692 1125">Default is disabled.</p> Enable MS UEFI CA key <p data-bbox="531 1205 1458 1255">Disabling this setting alters the Secure Boot key list to further restrict the allowed software components. Set this option to disable to support Device Guard.</p> Ready BIOS for Device Guard Use <p data-bbox="531 1335 1278 1356">Requires BIOS Administrator password to be configured and Secure Boot to be enabled.</p> |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|---|---|
| System Options | Configure storage controller for Intel Optane |
| | Enables the Intel® Optane™ memory module. |
| | Hyperthreading |
| | Lets you control processor capability. Default is enabled. |
| | Multiprocessor |
| | Use this option to disable multiprocessor support under the operating system. Default is enabled. |
| | Virtualization Technology (VTx) (Intel only) |
| | Controls the virtualization features of the processor. Changing this setting requires turning the computer off and then back on. Default is disabled. |
| | Virtualization Technology for Directed I/O (VTd) (Intel only) |
| | Controls virtualization DMA remapping features of the chipset. Changing this setting requires turning the computer off and then back on. Default is disabled. |
| | M.2 SSD |
| | Lets you disable the M.2 solid-state drive slot. Default is enabled. |
| M.2 WLAN/BT | |
| Lets you disable the wireless module slot. Default is enabled. | |
| Allow PCIe/PCI SERR# Interrupt (enable/disable) | |
| Allows PCI devices to report PCI/PCIe System Error signals, such as address parity errors, data parity errors, and critical errors other than parity. Default is enabled. | |
| Power Button Override (disable/4 sec/15 sec) | |
| Lets you disable or enable and select the number of seconds you have to hold down the power button for it to force the system to turn off. Default is 4 sec. | |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|---|--|
| Built-In Device Options | Embedded LAN Controller |
| | Select to show the device in the operating system. Default is enabled. |
| | Wake On LAN |
| | Lets you either disable the Wake On LAN feature or configure where the computer boots, including the network or hard drive. Default is Boot to Network. |
| | Allow No Panel configuration |
| | When enabled, POST blink and beep codes and error messages are not generated. Default is disabled. |
| | Video memory size |
| | Use this option to manage graphics memory allocation. The value you choose is allocated permanently to graphics and is unavailable to the operating system. |
| | Integrated Camera |
| | Clear to disable the integrated camera. Default is enabled. |
| | Audio Device |
| | Select to show the device in the operating system. Default is enabled. |
| | Integrated Microphone |
| | Clear to disable the integrated microphone. This does not affect devices plugged into audio jacks. Default is enabled. |
| | Internal Speakers (does not affect external speakers) |
| | Clear to disable the chassis speaker or speakers. This function is applicable to normal audio playback in the operating system and does not affect the error or warning beeps during POST. Default is enabled. |
| | Headphone Output |
| | Clear to disable the headphone jack. Default is enabled. |
| | Collaboration Buttons |
| | Clear to disable the collaboration buttons. Default is enabled. |
| Button Sensitivity | |
| Select from low, medium, or high. Default is low. | |
| LAN/WLAN auto switching | |
| Select to enable auto switching between a wired and wireless connection. Default is disabled. | |
| Wake on WLAN | |
| Select to enable wake on WLAN. Default is disabled. | |
| M.2 USB/Bluetooth | |
| Select to enable the M.2 controller. Default is enabled. | |
| Increase Idle Fan Speed(%) | |
| Sets idle fan speed percentage. This setting only changes the minimum fan speed. The fan is still automatically controlled. | |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading | |
|--------------|--|---|
| Port Options | SATA0 Lets you disable the connector. Default is enabled. | |
| | SATA1 Lets you disable the connector. Default is enabled. | |
| | Rear USB ports Lets you disable the ports. Default is enabled. | |
| | Right USB ports Lets you disable the ports. Default is enabled. | |
| | USB Legacy Port Charging Lets you enable USB charging port capability when the computer is in hibernate or shutdown mode. Default is enabled. | |
| | USB Type-C Downstream Charging Lets you enable USB charging port capability when the computer is in hibernate on or off. Default is enabled. | |
| | Restrict USB Devices Specify the following categories of USB devices to enable: | |
| | <ul style="list-style-type: none"> • Allow all USB devices (default) • Allow only keyboard and mouse • Allow all but storage devices and hubs. | |
| | When some devices are restricted, the system will disable USB ports that do not meet the allowed criteria. This feature is usually combined with similar policies within the operating system because USB devices can be moved to different ports. The ports disabled by the BIOS remain disabled until the system is restarted. | |
| | USB Type-C Controller Firmware Update Default is enabled. | |
| | Option ROM Launch Policy | These policies control whether Legacy Option ROMs or UEFI drivers are loaded. Default is All UEFI. |
| | | Configure Option ROM Launch Policy <ul style="list-style-type: none"> • All legacy • All UEFI • All UEFI except video |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|--|--|
| Power Management Options | Runtime Power Management (enable/disable) |
| | Allows certain operating systems to reduce processor voltage and frequency when the current software load does not require the full capabilities of the processor. Default is enabled. |
| | Extended Idle Power States (enable/disable) |
| | Allows certain operating systems to decrease the processors power consumption when the processor is idle. Default is enabled. |
| | S5 Maximum Power Savings (enable/disable) |
| | Enabling this feature reduces the power of the system as much as possible in the S5 state. Power is removed from the wake up circuitry, the expansion slots, and any management features while in S5. Default is disabled. |
| | SATA Power Management (enable/disable) |
| | Enables or disables SATA bus, device power management, or both. Default is enabled. |
| | PCI Express Power Management (enable/disable) |
| | Enabling this option permits the PCI Express links to use Active Power State Management (ASPM) to enter lower power states while not in use. Default is enabled. |
| Power On from Keyboard Ports (enable/disable) | |
| When enabled, this feature allows a key press to turn on the system when it is off (S5 state). If using a USB keyboard, you must plug it into one of the rear ports labeled with the keyboard icon. Default is disabled. | |
| Unique Sleep State Blink Rates (enable/disable) | |
| This feature is designed to provide a visual indication of what Sleep state the system is in. Each Sleep state has a unique blink pattern. Default is disabled. | |
| NOTE: A normal shutdown goes to the S4 state for Windows 8 or later. | |
| S0 (On) = solid white light. | |
| S3 (Stand By) = 3 blinks at 1 Hz (50% duty cycle) followed by a pause of 2 seconds (white light), repeated cycles of 3 blinks and a pause. | |
| S4 (Hibernation) = 4 blinks at 1 Hz (50% duty cycle) followed by a pause of 2 seconds (white light), repeated cycles of 4 blinks and a pause. | |
| S5 (Soft Off) = Light is off. | |

Table 6-3 Computer Setup—Advanced (for advanced users) (continued)

| Option | Heading |
|---------------------------|--|
| Electronic labels | Displays system labels. |
| Remote Management Options | <p>Active Management (AMT) (Intel only) (enable/disable). Default is enabled.</p> <p>Allows you to discover, repair, and protect networked computing devices.</p> <p>USB Key Provisioning Support (enable/disable) Default is disabled.</p> <p>USB Redirection Support (enable/disable). Default is enabled.</p> <p>USB redirection allows USB devices plugged into a client computer to be transparently redirected to the guest operating system.</p> <p>Unconfigure AMT on next boot (Do Not Apply/Apply). Default is Do Not Apply.</p> <p>SOL Terminal Emulation Mode (ANSI / VT100). Default is ANSI.</p> <p>SOL (serial-over-LAN) terminal emulation mode is only activated during remote AMT (Active Management Technology) redirection operations. The emulation options allow administrators to select which mode works best with their console.</p> <p>Show Unconfigure ME Confirmation Prompt (enable/disable). Default is enabled.</p> <p>Verbose Boot Messages (enable/disable). Default is enabled.</p> <p>Verbose boot shows additional logging information during startup, which is mainly for debugging if something goes wrong during bootup.</p> <p>Watchdog Timer (enable/disable). Default is enabled.</p> <p>Allows you to set amount of time for a operating system and BIOS watchdog alert to be sent if the timers are not deactivated. BIOS watchdog is deactivated by BIOS and would indicate that a halt occurred during execution if the alert is sent to the management console. An operating system alert is deactivated by the operating system image and would indicate that a hang occurred during its initialization.</p> <ul style="list-style-type: none">• OS Watchdog Timer (min.) – (5/10/15/20/25). Default is 5 min.• BIOS Watchdog Timer (min.) – (5/10/15/20/25). Default is 5 min. <p>CIRA Timeout (min.) (1/2/3/4/Never)</p> <p>CIRA is Customer Initiated Remote Assistance, an Intel service to help users employing Active Management Technology (AMT).</p> |

7 POST error messages

This section lists the error codes, error messages, and the various indicator light and audible sequences that you may encounter during Power-On Self-Test (POST) or computer restart, the probable source of the problem, and steps you can take to resolve the error condition.

POST Message Disabled suppresses most system messages during POST, such as memory count and non-error text messages. If a POST error occurs, the screen will display the error message. To manually switch to the POST Messages Enabled mode during POST, press any key (except **f10**, **f11**, or **f12**). The default mode is POST Message Disabled.

The POST mode selection determines the speed at which the computer loads the operating system and the extent to which it is tested.

Quick Boot is a fast startup process that does not run all of the system level tests, such as the memory test. Full Boot runs all of the ROM-based system tests and takes longer to complete.

You can enable Full Boot to run every 1 to 30 days on a regularly scheduled basis. To establish the schedule, reconfigure the computer to the Full Boot Every x Days mode, using Computer Setup.

 **NOTE:** For more information about Computer Setup, see [Computer Setup \(F10\) Utility on page 75](#).

POST numeric codes and text messages

This section identifies those POST errors that have numeric codes associated with them. The section also includes some text messages that you might encounter during POST.

 **NOTE:** The computer beeps once after a POST text message is displayed on the screen.

Table 7-1 POST numeric codes and text messages

| Control panel message | Description | Recommended action |
|-------------------------------|--|--|
| 101-Option ROM Checksum Error | System ROM or expansion board option ROM checksum. | <ol style="list-style-type: none">1. Verify the correct ROM.2. Flash the ROM if needed.3. If an expansion board was recently added, remove it to see if the problem remains.4. Clear CMOS.5. If the message disappears, there might be a problem with the expansion card.6. Replace the system board. |

Table 7-1 POST numeric codes and text messages (continued)

| Control panel message | Description | Recommended action |
|--|--|--|
| 103-System Board Failure | DMA or timers. | <ol style="list-style-type: none"> 1. Clear CMOS. 2. Replace the system board. |
| 162-System Options Not Set | <p>Configuration incorrect.</p> <p>RTC (real-time clock) battery might need to be replaced.</p> | <p>Run Computer Setup and check the configuration in Advanced > Onboard Devices.</p> <p>Reset the date and time under Control Panel. If the problem persists, replace the RTC battery.</p> |
| 163-Time & Date Not Set | <p>Invalid time or date in configuration memory.</p> <p>RTC (real-time clock) battery may need to be replaced.</p> | <p>Reset the date and time under Control Panel (You can also use Computer Setup). If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.</p> |
| 163-Time & Date Not Set | CMOS jumper might not be properly installed. | Check for proper placement of the CMOS jumper if applicable. |
| 164-MemorySize Error | Memory amount has changed since the last boot (memory added or removed). | Press the f1 key to save the memory changes. |
| 164-MemorySize Error | Memory configuration incorrect. | <ol style="list-style-type: none"> 1. Run Computer Setup or Windows utilities. 2. Be sure the memory modules are installed properly. 3. If third-party memory has been added, test using HP-only memory. 4. Verify proper memory module type. |
| 201-Memory Error | RAM failure. | <ol style="list-style-type: none"> 1. Be sure that memory modules are correctly installed. 2. Verify proper memory module type. 3. Remove and replace the identified faulty memory modules. 4. If the error persists after replacing memory modules, replace the system board. |
| 213-Incompatible Memory Module in Memory Socket(s) X, X, ... | A memory module in memory socket identified in the error message is missing critical SPD information, or is incompatible with the chipset. | <ol style="list-style-type: none"> 1. Verify proper memory module type. 2. Try another memory socket. 3. Replace DIMM with a module conforming to the SPD standard. |
| 214-DIMM Configuration Warning | Populated DIMM Configuration is not optimized. | Rearrange the DIMMs so that each channel has the same amount of memory. |

Table 7-1 POST numeric codes and text messages (continued)

| Control panel message | Description | Recommended action |
|---|--|--|
| 219-ECC Memory Module Detected ECC Modules not supported on this Platform | Recently added memory modules support ECC memory error correction. | <ol style="list-style-type: none"> 1. If additional memory was recently added, remove it to see if the problem remains. 2. Check product documentation for memory support information. |
| 301-Keyboard Error | Keyboard failure. | <ol style="list-style-type: none"> 1. Reconnect keyboard with computer turned off. 2. Check connector for bent or missing pins. 3. Be sure that none of the keys are depressed. 4. Replace keyboard. |
| 303-Keyboard Controller Error | I/O board keyboard controller. | <ol style="list-style-type: none"> 1. Reconnect keyboard with computer turned off. 2. Replace the system board. |
| 304-Keyboard or System Unit Error | Keyboard failure. | <ol style="list-style-type: none"> 1. Reconnect the keyboard with computer turned off. 2. Be sure that none of the keys are depressed. 3. Replace the keyboard. 4. Replace the system board. |
| 501-Display Adapter Failure | Graphics display controller. | <ol style="list-style-type: none"> 1. Clear CMOS. 2. Verify that the monitor is attached and turned on. |
| 510-Flash Screen Image Corrupted | Flash Screen image has errors. | Reflash the system ROM with the latest BIOS image. |
| 512-Chassis, Rear Chassis, or Front Chassis Fan not Detected | Fan is not connected or might have malfunctioned. | <ol style="list-style-type: none"> 1. Reseat fan. 2. Reseat fan cable. 3. Replace fan. |
| 514-CPU or Chassis Fan not Detected | Fan is not connected or might have malfunctioned. | <ol style="list-style-type: none"> 1. Reseat fan. 2. Reseat fan cable. 3. Replace fan. |
| 660-Display cache is detected unreliable | Integrated graphics controller display cache is not working properly and will be disabled. | Replace system board if minimal graphics degrading is an issue. |
| 1720-SMART Hard Drive Detects Imminent Failure | Hard drive will soon fail. (Some hard drives have a hard drive firmware patch that will fix an erroneous error message.) | <ol style="list-style-type: none"> 1. Determine if hard drive is giving correct error message. Run the Drive Protection System test under Using F2 |

Table 7-1 POST numeric codes and text messages (continued)

| Control panel message | Description | Recommended action |
|--|--|--|
| | | <p>Diagnostics when booting the computer.</p> <ol style="list-style-type: none"> Apply hard drive firmware patch if applicable. (Available at http://www.hp.com/support.) Back up contents and replace hard drive. |
| 2212-USB Key Provisioning failure writing to device | USB device used for USB key provisioning will not allow BIOS to update provision file properly. | <ol style="list-style-type: none"> Try a different USB key device for provisioning. If the error persists, update to the latest BIOS version and ME firmware version. If the error still persists, replace the system board. |
| 2217-ME Firmware Version request failure | ME firmware does not properly respond to BIOS query for version information. | <ol style="list-style-type: none"> Reboot the computer. If the error persists, update to the latest BIOS version and ME firmware version. If the error still persists, replace the system board. |
| 2218-ME Firmware Version should be updated | ME firmware must be updated to match current functionality contained in the system BIOS. | <ol style="list-style-type: none"> Update to the latest ME firmware version. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. If the error still persists, replace the system board. |
| 2219-USB Key Provisioning file has invalid header identifier | Provisioning file contained on the USB key has been corrupted or is not a valid version for the current ME firmware. | <ol style="list-style-type: none"> Recreate the provisioning file using third-party management console software. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version. If the error still persists, replace the system board. |
| 2220-USB Key Provisioning file has mismatch version | Provisioning file contained on the USB key is not a valid version for the current ME firmware. | <ol style="list-style-type: none"> Reboot the computer. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version. If the error still persists, replace the system board. |

Table 7-1 POST numeric codes and text messages (continued)

| Control panel message | Description | Recommended action |
|---|---|--|
| Invalid Electronic Serial Number | Electronic serial number is missing. | Enter the correct serial number in Computer Setup. |
| Network Server Mode Active and No Keyboard Attached | Keyboard failure while Network Server Mode enabled. | <ol style="list-style-type: none"> 1. Reconnect keyboard with computer turned off. 2. Check connector for bent or missing pins. 3. Be sure that none of the keys are depressed. 4. Replace keyboard. |
| Parity Check 2 | Parity RAM failure. | Run Computer Setup and Diagnostic utilities. |

Interpreting POST diagnostic front panel lights and audible codes

This section identifies the front panel light codes as well as the audible codes that can occur before or during POST that might not have an error code or text message associated with them.

CAUTION: When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the AC outlet and allow the internal system components to cool before touching.

NOTE: If you see blinking lights on a PS/2 keyboard, look for blinking lights on the front panel of the computer and see the following table to determine the front panel light codes.

Recommended actions in the following table are listed in the order in which they should be performed.

Not all diagnostic lights and audible codes are available on all models.

Table 7-2 Interpreting POST diagnostic front panel lights and audible codes

| Activity | Beeps | Possible cause | Recommended action |
|---|-------|---|---|
| White power light on. | None | Computer on. | None |
| White power light blinks every two seconds. | None | Computer in Suspend to RAM mode (some models only) or normal Suspend mode. | None required. Press any key or move the mouse to wake the computer. |
| Red power light blinks two times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 2 | <p>Processor thermal protection activated:</p> <p>A fan might be blocked or not turning.</p> <p>OR</p> <p>The heat sink and fan assembly is not properly attached to the processor.</p> | <ol style="list-style-type: none"> 1. Be sure that the computer air vents are not blocked and that the cooling fan is running. 2. Open hood, press power button, and see if the fan spins. If the processor fan is not spinning, be sure the fan's cable is plugged onto the system board header. 3. If fan is plugged in but is not spinning, then replace fan. 4. Contact an authorized reseller or service provider. |

Table 7-2 Interpreting POST diagnostic front panel lights and audible codes (continued)

| Activity | Beeps | Possible cause | Recommended action |
|---|-------|---|---|
| Red power light blinks four times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 4 | Power failure (power supply is overloaded). | <ol style="list-style-type: none"> 1. Check if a device is causing the problem by removing all attached devices. Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly. 2. Replace the power supply. 3. Replace the system board. |
| Red power light blinks five times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 5 | Pre-video memory error. | <p>IMPORTANT: To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a DIMM module.</p> <ol style="list-style-type: none"> 1. Reseat DIMMs. 2. Replace DIMMs one at a time to isolate the faulty module. 3. Replace third-party memory with HP memory. 4. Replace the system board. |
| Red power light blinks six times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 6 | Pre-video graphics error. | Replace the system board. |
| Red power light blinks seven times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 7 | System board failure (ROM detected failure prior to video). | Replace the system board. |
| Red power light blinks eight times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 8 | Invalid ROM based on bad checksum. | <ol style="list-style-type: none"> 1. Reflash the system ROM with the latest BIOS image. 2. Replace the system board. |

Table 7-2 Interpreting POST diagnostic front panel lights and audible codes (continued)

| Activity | Beeps | Possible cause | Recommended action |
|--|-------|---------------------------------|---|
| Red power light blinks nine times, once every second, followed by a two-second pause. Beeps stop after fifth iteration, but lights continue until problem is solved. | 9 | System turn on but cannot boot. | <ol style="list-style-type: none"> 1. Unplug the power cord from the computer, wait 30 s, then plug the power cord back in to the computer. 2. Replace the system board. |
| System does not turn on and lights are not blinking. | None | System cannot start. | <p>Press and hold the power button for less than 4 seconds. If the hard drive light turns white, the power button is working correctly.</p> <p>▲ Replace the system board.</p> <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive light does not turn on white then:</p> <ol style="list-style-type: none"> 1. Be sure that the unit is plugged into a working AC outlet. 2. Replace the power supply. |

8 Password security and resetting CMOS

This computer supports two security password features that you can establish through the Computer Setup Utilities menu: administrator password and power-on password.

When you establish only an administrator password, any user can access all the information on the computer except Computer Setup. When you establish only a power-on password, the power-on password is required to access Computer Setup and any other information on the computer. When you establish both passwords, only the administrator password will give you access to Computer Setup.

When both passwords are set, you can use the administrator password in place of the power-on password as an override to log in to the computer. This feature is useful for a network administrator.

 **IMPORTANT:** Back up the BIOS settings or save them as custom defaults in case you need them later. You can back up in Computer Setup or with the BiosConfigUtility tool available from www.hp.com. See [Computer Setup \(F10\) Utility on page 75](#) for information about backing up the BIOS settings.

Changing a setup or power-on password

Use this procedure to change a password.

To change the power-on or setup password, complete the following steps:

1. Turn on or restart the computer.
To change the setup password, go to step 2.
To change the power-on password, go to step 3.
2. To change the setup password, as soon as the computer turns on:
 - Press **esc** while the “Press the ESC key for Startup Menu” message is displayed.
 - Press **f10** to enter Computer Setup.
3. When the key icon appears, type your current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown:

current password/new password/new password

 **NOTE:** Type the new password carefully because the characters do not appear on the screen.

4. Press **enter**.

The new password will take effect the next time the computer is restarted.

Deleting a setup or power-on password

Use this procedure to delete a password.

To delete the power-on or setup password, complete the following steps:

1. Turn on or restart the computer.

To delete the Setup password, go to step 2.

To delete the Power-on password, go to step 3.

2. To delete the Setup password, as soon as the computer turns on:

- Press **esc** while the “Press the ESC key for Startup Menu” message is displayed.

- Press **f10** to enter Computer Setup.

3. When the key icon appears, type your current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown:

current password/

4. Press **enter**.

9 Using HP PC Hardware Diagnostics

You can use the HP PC Hardware Diagnostics utility to determine whether your computer hardware is running properly. The three versions are HP PC Hardware Diagnostics Windows, HP PC Hardware Diagnostics UEFI (Unified Extensible Firmware Interface), and (for select products only) Remote HP PC Hardware Diagnostics UEFI, a firmware feature.

Using HP PC Hardware Diagnostics Windows (select products only)

HP PC Hardware Diagnostics Windows is a Windows-based utility that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs within the Windows operating system to diagnose hardware failures.

If HP PC Hardware Diagnostics Windows is not installed on your computer, first you must download and install it. To download HP PC Hardware Diagnostics Windows, see [Downloading HP PC Hardware Diagnostics Windows on page 104](#).

Using an HP PC Hardware Diagnostics Windows hardware failure ID code

When HP PC Hardware Diagnostics Windows detects a failure that requires hardware replacement, a 24-digit Failure ID code is generated.

- ▲ Depending on the instructions on the screen, choose one of these options:
 - If failure ID link is displayed, select the link and follow the on-screen instructions.
 - If instructions for calling support are displayed. Follow those instructions.

Accessing HP PC Hardware Diagnostics Windows

After HP PC Hardware Diagnostics Windows is installed, you can access it from HP Help and Support or HP Support Assistant.

Accessing HP PC Hardware Diagnostics Windows from HP Help and Support

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from HP Help and Support.

To access HP PC Hardware Diagnostics Windows from HP Help and Support:

1. Select the **Start** button, and then select **HP Help and Support**.
2. Select **HP PC Hardware Diagnostics Windows**.
3. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

 **NOTE:** To stop a diagnostic test, select **Cancel**.

Accessing HP PC Hardware Diagnostics Windows from Support Assistant

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from HP Support Assistant.

To access HP PC Hardware Diagnostics Windows from HP Support Assistant:

1. Type `support` in the taskbar search box, and then select the **HP Support Assistant** app.
– or –
Select the question mark icon in the taskbar.
2. Select **Troubleshooting and fixes**.
3. Select **Diagnostics**, and then select **HP PC Hardware Diagnostics Windows**.
4. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

 **NOTE:** To stop a diagnostic test, select **Cancel**.

Downloading HP PC Hardware Diagnostics Windows

The HP PC Hardware Diagnostics Windows downloading instructions are provided in English only. You must use a Windows computer to download this tool because only .exe files are provided.

Downloading the latest HP PC Hardware Diagnostics Windows version from HP

To download HP PC Hardware Diagnostics Windows from HP, follow these steps.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. Select **Download HP Diagnostics Windows**, and then select a location on your computer or a USB flash drive.

The tool downloads to the selected location.

Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store

You can download the HP PC Hardware Diagnostics Windows from the Microsoft Store.

1. Select the Microsoft Store app on your desktop or enter `Microsoft Store` in the taskbar search box.
2. Enter `HP PC Hardware Diagnostics Windows` in the **Microsoft Store** search box.
3. Follow the on-screen directions.

The tool downloads to the selected location.

Downloading HP Hardware Diagnostics Windows by product name or number (select products only)

You can download HP PC Hardware Diagnostics Windows by product name or number.



NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Select **Software and Drivers**, select your type of product, and then enter the product name or number in the search box that is displayed.
3. In the **Diagnostics** section, select **Download**, and then follow the on-screen instructions to select the specific Windows diagnostics version to be downloaded to your computer or USB flash drive.

The tool downloads to the selected location.

Installing HP PC Hardware Diagnostics Windows

To install HP PC Hardware Diagnostics Windows, navigate to the folder on your computer or the USB flash drive where the .exe file downloaded, double-click the .exe file, and then follow the on-screen instructions.

Using HP PC Hardware Diagnostics UEFI

HP PC Hardware Diagnostics UEFI (Unified Extensible Firmware Interface) allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.

 **NOTE:** For Windows 10 S computers, you must use a Windows computer and a USB flash drive to download and create the HP UEFI support environment because only .exe files are provided. For more information, see [Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive on page 106](#).

If your PC does not start in Windows, you can use HP PC Hardware Diagnostics UEFI to diagnose hardware issues.

Using an HP PC Hardware Diagnostics UEFI hardware failure ID code

When HP PC Hardware Diagnostics UEFI detects a failure that requires hardware replacement, a 24-digit Failure ID code is generated.

For assistance in solving the problem:

- ▲ Select **Contact HP**, accept the HP privacy disclaimer, and then use a mobile device to scan the Failure ID code that appears on the next screen. The HP Customer Support - Service Center page appears with your Failure ID and product number automatically filled in. Follow the on-screen instructions.

– or –

Contact support, and provide the Failure ID code.

 **NOTE:** To start diagnostics on a convertible computer, your computer must be in notebook mode, and you must use the attached keyboard.

 **NOTE:** If you need to stop a diagnostic test, press [esc](#).

Starting HP PC Hardware Diagnostics UEFI

To start HP PC Hardware Diagnostics UEFI, follow this procedure.

1. Turn on or restart the computer, and quickly press [esc](#).
2. Press [f2](#).

The BIOS searches three places for the diagnostic tools, in the following order:

- a. Connected USB flash drive

 **NOTE:** To download the HP PC Hardware Diagnostics UEFI tool to a USB flash drive, see [Downloading the latest HP PC Hardware Diagnostics UEFI version on page 106](#).

- b. Hard drive

- c. BIOS

3. When the diagnostic tool opens, select a language, select the type of diagnostic test you want to run, and then follow the on-screen instructions.

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive can be useful in some situations.

- HP PC Hardware Diagnostics UEFI is not included in the preinstallation image.
- HP PC Hardware Diagnostics UEFI is not included in the HP Tool partition.
- The hard drive is damaged.



NOTE: The HP PC Hardware Diagnostics UEFI downloading instructions are provided in English only, and you must use a Windows computer to download and create the HP UEFI support environment because only .exe files are provided.

Downloading the latest HP PC Hardware Diagnostics UEFI version

To download the latest HP PC Hardware Diagnostics UEFI version to a USB flash drive, follow this procedure.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. Select **Download HP Diagnostics UEFI**, and then select **Run**.

Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only)

You can download HP PC Hardware Diagnostics UEFI by product name or number (select products only) to a USB flash drive.



NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Enter the product name or number, select your computer, and then select your operating system.
3. In the **Diagnostics** section, follow the on-screen instructions to select and download the specific UEFI Diagnostics version for your computer.

Using Remote HP PC Hardware Diagnostics UEFI settings (select products only)

Remote HP PC Hardware Diagnostics UEFI is a firmware (BIOS) feature that downloads HP PC Hardware Diagnostics UEFI to your computer. It can then execute the diagnostics on your computer, and it might upload results to a preconfigured server.

For more information about Remote HP PC Hardware Diagnostics UEFI, go to <http://www.hp.com/go/techcenter/pcdiags>, and then select **Find out more**.

Downloading Remote HP PC Hardware Diagnostics UEFI

HP Remote PC Hardware Diagnostics UEFI is also available as a SoftPak that you can download to a server.

Downloading the latest Remote HP PC Hardware Diagnostics UEFI version

You can download the latest HP PC Hardware Diagnostics UEFI version to a USB flash drive.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. Select **Download Remote Diagnostics**, and then select **Run**.

Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number

You can download HP Remote PC Hardware Diagnostics UEFI by product name or number.



NOTE: For some products, you might have to download the software by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Select **Software and Drivers**, select your type of product, enter the product name or number in the search box that is displayed, select your computer, and then select your operating system.
3. In the **Diagnostics** section, follow the on-screen instructions to select and download the **Remote UEFI** version for the product.

Customizing Remote HP PC Hardware Diagnostics UEFI settings

Using the Remote HP PC Hardware Diagnostics setting in Computer Setup (BIOS), you can perform several customizations.

- Set a schedule for running diagnostics unattended. You can also start diagnostics immediately in interactive mode by selecting **Execute Remote HP PC Hardware Diagnostics**.
- Set the location for downloading the diagnostic tools. This feature provides access to the tools from the HP website or from a server that has been preconfigured for use. Your computer does not require the traditional local storage (such as a hard drive or USB flash drive) to run remote diagnostics.
- Set a location for storing the test results. You can also set the user name and password that you use for uploads.
- Display status information about the diagnostics run previously.

To customize Remote HP PC Hardware Diagnostics UEFI settings, follow these steps:

1. Turn on or restart the computer, and when the HP logo appears, press **F10** to enter Computer Setup.
2. Select **Advanced**, and then select **Settings**.
3. Make your customization selections.
4. Select **Main**, and then **Save Changes and Exit** to save your settings.

Your changes take effect when the computer restarts.

10 Backing up, restoring, and recovering

You can use Windows tools or HP software to back up your information, create a restore point, reset your computer, create recovery media, or restore your computer to its factory state. Performing these standard procedures can return your computer to a working state faster.

 **IMPORTANT:** If you will be performing recovery procedures on a tablet, the tablet battery must be at least 70% charged before you start the recovery process.

IMPORTANT: For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning any recovery process.

Backing up information and creating recovery media

These methods of creating recovery media and backups are available on select products only.

Using Windows tools for backing up

HP recommends that you back up your information immediately after initial setup. You can do this task either using Windows Backup locally with an external USB drive or using online tools.

 **IMPORTANT:** Windows is the only option that allows you to back up your personal information. Schedule regular backups to avoid information loss.

 **NOTE:** If computer storage is 32 GB or less, Microsoft System Restore is disabled by default.

Using the HP Cloud Recovery Download Tool to create recovery media (select products only)

You can use the HP Cloud Recovery Download Tool to create HP Recovery media on a bootable USB flash drive.

For details:

▲ Go to <http://www.hp.com/support>, search for HP Cloud Recovery, and then select the result that matches the type of computer that you have.

 **NOTE:** If you cannot create recovery media yourself, contact support to obtain recovery discs. Go to <http://www.hp.com/support>, select your country or region, and then follow the on-screen instructions.

 **IMPORTANT:** HP recommends that you follow the [Restoring and recovery methods on page 111](#) to restore your computer before you obtain and use the HP recovery discs. Using a recent backup can return your machine to a working state sooner than using the HP recovery discs. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Restoring and recovering your system

You have several tools available to recover your system both within and outside of Windows if the desktop cannot load.

HP recommends that you attempt to restore your system using the [Restoring and recovery methods on page 111](#).

Creating a system restore

System Restore is available in Windows. The System Restore software can automatically or manually create restore points, or snapshots, of the system files and settings on the computer at a particular point.

When you use System Restore, it returns your computer to its state at the time you made the restore point. Your personal files and documents should not be affected.

Restoring and recovery methods

After you run the first method, test to see whether the issue still exists before you proceed to the next method, which might now be unnecessary.

1. Run a Microsoft System Restore.
2. Run Reset this PC.
3. Recover using HP Recovery media. For more information, see [Recovering using HP Recovery media on page 111](#).

For more information about the first two methods, see the Get Help app:

Select the **Start** button, select the **Get Help** app, and then enter the task you want to perform.



NOTE: You must be connected to the internet to access the Get Help app.

Recovering using HP Recovery media

You can use HP Recovery media to recover the original operating system and software programs that were installed at the factory. On select products, it can be created on a bootable USB flash drive using the HP Cloud Recovery Download Tool.

For details, see [Using the HP Cloud Recovery Download Tool to create recovery media \(select products only\) on page 110](#).



NOTE: If you cannot create recovery media yourself, contact support to obtain recovery discs. Go to <http://www.hp.com/support>, select your country or region, and then follow the on-screen instructions.

To recover your system:

- ▲ Insert the HP Recovery media, and then restart the computer.



NOTE: HP recommends that you follow the [Restoring and recovery methods on page 111](#) to restore your computer before you obtain and use the HP recovery discs. Using a recent backup can return your machine to a working state sooner than using the HP recovery discs. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Changing the computer boot order

If your computer does not restart using the HP Recovery media, you can change the computer boot order, the order of devices listed in BIOS for startup information. You can select an optical drive or a USB flash drive, depending on the location of your HP Recovery media.

 **IMPORTANT:** For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning these steps.

To change the boot order:

1. Insert the HP Recovery media.
2. Access the system **Startup** menu.
 - For computers or tablets with keyboards attached, turn on or restart the computer or tablet, quickly press **esc**, and then press **f9** for boot options.
 - For tablets without keyboards, turn on or restart the tablet, quickly press and hold the volume up button, and then select **f9**.

– or –

Turn on or restart the tablet, quickly press and hold the volume down button, and then select **f9**.
3. Select the optical drive or USB flash drive from which you want to boot, and then follow the on-screen instructions.

Using HP Sure Recover (select products only)

Select computer models are configured with HP Sure Recover, a PC OS recovery solution built into the hardware and software. HP Sure Recover can fully restore the HP OS image without installed recovery software.

Using HP Sure Recover, an administrator or user can restore the system and install:

- Latest version of the operating system
- Platform-specific device drivers
- Software applications, in the case of a custom image

To access the latest documentation for HP Sure Recover, go to <http://www.hp.com/support>. Follow the on-screen instructions to find your product and locate your documentation.

11 Statement of memory volatility

For general information regarding nonvolatile memory in HP Business computers, and to restore nonvolatile memory that can contain personal data after the system has been turned off and the hard drive has been removed, use these instructions.

HP Business computer products that use Intel®-based or AMD®-based system boards contain volatile DDR memory. The amount of nonvolatile memory present in the system depends upon the system configuration. Intel-based and AMD-based system boards contain nonvolatile memory subcomponents as originally shipped from HP, with the following assumptions:

- No subsequent modifications were made to the system.
- No applications, features, or functionality were added to or installed on the system.

Following system shutdown and removal of all power sources from an HP Business computer system, personal data can remain on volatile system memory (DIMMs) for a finite period of time and also remains in nonvolatile memory. Use the following steps to remove personal data from the computer, including the nonvolatile memory found in Intel-based and AMD-based system boards.

 **NOTE:** If your tablet has a keyboard base, connect to the keyboard base before beginning steps in this chapter.

Current BIOS steps

Use these instructions to restore nonvolatile memory.

1. Follow these steps to restore the nonvolatile memory that can contain personal data. Restoring or reprogramming nonvolatile memory that does not store personal data is neither necessary nor recommended.

- a. Turn on or restart the computer, and then quickly press **esc**.

 **NOTE:** If the system has a BIOS administrator password, enter the password at the prompt.

- b. Select **Main**, select **Apply Factory Defaults and Exit**, and then select **Yes** to load defaults. The computer restarts.
- c. During the restart, press **esc** while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.

 **NOTE:** If the system has a BIOS administrator password, enter the password at the prompt.

- d. Select the **Security** menu, select **Restore Security Settings to Factory Defaults**, and then select **Yes** to restore security level defaults. The computer reboots.

- e. During the reboot, press **esc** while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.



NOTE: If the system has a BIOS administrator password, enter the password at the prompt.

- f. If an asset or ownership tag is set, select the **Security** menu and scroll down to the **Utilities** menu. Select **System IDs**, and then select **Asset Tracking Number**. Clear the tag, and then make the selection to return to the prior menu.
- g. If a DriveLock password is set, select the **Security** menu, and scroll down to **Hard Drive Utilities** under the **Utilities** menu. Select **Hard Drive Utilities**, select **DriveLock**, and then clear the check box for **DriveLock password on restart**. Select **OK** to proceed.
- h. Select the **Main** menu, and then select **Reset BIOS Security to factory default**. Click **Yes** at the warning message. The computer reboots.
- i. During the reboot, press **esc** while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.



NOTE: If the system has a BIOS administrator password, enter the password at the prompt.

- j. Select the **Main** menu, select **Apply Factory Defaults and Exit**, select **Yes** to save changes and exit, and then select **Shutdown**.
 - k. Reboot the system. If the system has a Trusted Platform Module (TPM), fingerprint reader, or both, one or two prompts will appear—one to clear the TPM and the other to Reset Fingerprint Sensor. Press or tap **f1** to accept or **f2** to reject.
 - l. Remove all power and system batteries for at least 24 hours.
2. Complete one of the following:
- Remove and retain the storage drive.
– or –
 - Clear the drive contents by using a third-party utility designed to erase data from an SSD.
– or –
 - Clear the contents of the drive by using the following BIOS Setup Secure Erase command option steps:

If you clear data using Secure Erase, you cannot recover it.

- a. Turn on or restart the computer, and then quickly press **esc**.
- b. Select the **Security** menu and scroll down to the **esc** menu.
- c. Select **Hard Drive Utilities**.
- d. Under **Utilities**, select **Secure Erase**, select the hard drive storing the data you want to clear, and then follow the on-screen instructions to continue.

– or –

Clear the contents of the drive using the following Disk Sanitizer commands steps:

- i. Turn on or restart the computer, and then quickly press **esc**.
- ii. Select the **Security** menu and scroll down to the **Utilities** menu.
- iii. Select **Hard Drive Utilities**.
- iv. Under **Utilities**, select **Disk Sanitizer**, select the hard drive with the data that you want to clear, and then follow the on-screen instructions to continue.

 **NOTE:** The amount of time it takes for Disk Sanitizer to run can take several hours. Plug the computer into an AC outlet before starting.

Nonvolatile memory usage

Use this table to troubleshooting nonvolatile memory usage.

Table 11-1 Troubleshooting steps for nonvolatile memory usage

| Nonvolatile memory type | Amount (Size) | Does this memory store customer data? | Does this memory retain data when power is removed? | What is the purpose of this memory? | How is data entered into this memory? | How is this memory write-protected? |
|---|---------------------------------|---------------------------------------|---|--|---|---|
| HP Sure Start flash (select models only) | 8 MB | No | Yes | Provides protected backup of critical System BIOS code, EC firmware, and critical computer configuration data for select platforms that support HP Sure Start. For more information, see Using HP Sure Start (select products only) on page 119 . | Data cannot be written to this device via the host processor. The content is managed solely by the HP Sure Start Embedded Controller. | This memory is protected by the HP Sure Start Embedded Controller. |
| Real Time Clock (RTC) battery backed-up CMOS configuration memory | 256 bytes | No | Yes | Stores system date and time and noncritical data. | RTC battery backed-up CMOS is programmed using Computer Setup (BIOS), or by changing the Windows date & time. | This memory is not write-protected. |
| Controller (NIC) EEPROM | 64 KB (not customer accessible) | No | Yes | Stores NIC configuration and NIC firmware. | NIC EEPROM is programmed using a utility from the NIC vendor that can be run from DOS. | A utility must be used to write data to this memory and is available from the NIC vendor. Writing data to this ROM in an inappropriate manner will render the NIC non-functional. |

Table 11-1 Troubleshooting steps for nonvolatile memory usage (continued)

| Nonvolatile memory type | Amount (Size) | Does this memory store customer data? | Does this memory retain data when power is removed? | What is the purpose of this memory? | How is data entered into this memory? | How is this memory write-protected? |
|---|---|---------------------------------------|---|---|---|--|
| DIMM Serial Presence Detect (SPD) configuration data | 256 bytes per memory module, 128 bytes programmable (not customer accessible) | No | Yes | Stores memory module information. | DIMM SPD is programmed by the memory vendor. | Data cannot be written to this memory when the module is installed in a computer. The specific write-protection method varies by memory vendor. |
| System BIOS | 9 MB | Yes | Yes | Stores system BIOS code and computer configuration data. | System BIOS code is programmed at the factory. Code is updated when the system BIOS is updated. Configuration data and settings are entered using the Computer Setup (BIOS) or a custom utility. | NOTE: Writing data to this ROM in an inappropriate manner can render the computer non-functional. A utility must be used for writing data to this memory and is available on the HP website; go to http://www.hp.com/support . Select Find your product , and then follow the on-screen instructions. |
| Intel Management Engine Firmware (present only in select Elite or Z models. For more information, go to http://www.hp.com/support . Select Identify your product for manuals and specific product information , and then follow the on-screen instructions.) | 1.5 MB or 7 MB | Yes | Yes | Stores Management Engine Code, Settings, Provisioning Data and iAMT third-party data store. | Management Engine Code is programmed at the factory. Code is updated via Intel secure firmware update utility. Unique Provisioning Data can be entered at the factory or by an administrator using the Management Engine (MEBx) setup utility. The third-party data store contents can be populated by a remote management console or local applications that have been registered by an administrator to have access to the space. | The Intel chipset is configured to enforce hardware protection to block all direct read-write access to this area. An Intel utility must be used for updating the firmware. Only firmware updates digitally signed by Intel can be applied using this utility. |
| Bluetooth flash (select products only) | 2 megabits | No | Yes | Stores Bluetooth configuration and firmware. | Bluetooth flash is programmed at the factory. Tools for writing data to this memory are not publicly available but can be obtained from the silicon vendor. | A utility must be used for writing data to this memory and is made available through newer versions of the driver whenever the flash requires an upgrade. |
| 802.11 WLAN EEPROM | 4 kilobits to 8 kilobits | No | Yes | Stores configuration and calibration data. | 802.11 WLAN EEPROM is programmed at the factory. Tools for writing data to this memory are not made public. | A utility must be used for writing data to this memory and is typically not made available to the public unless a firmware upgrade is necessary to address a unique issue. |

Table 11-1 Troubleshooting steps for nonvolatile memory usage (continued)

| Nonvolatile memory type | Amount (Size) | Does this memory store customer data? | Does this memory retain data when power is removed? | What is the purpose of this memory? | How is data entered into this memory? | How is this memory write-protected? |
|---|---------------|---------------------------------------|---|---|--|--|
| Camera (select products only) | 64 kilobits | No | Yes | Stores camera configuration and firmware. | Camera memory is programmed using a utility from the device manufacturer that can be run from Windows. | A utility must be used for writing data to this memory and is typically not made available to the public unless a firmware upgrade is necessary to address a unique issue. |
| Fingerprint reader (select products only) | 512 KB flash | Yes | Yes | Stores fingerprint templates. | Fingerprint reader memory is programmed by user enrollment in HP ProtectTools Security Manager. | Only a digitally signed application can make the call to write to the flash. |

Questions and answers

Use this section to answer your questions about nonvolatile memory.

1. How can the BIOS settings be restored (returned to factory settings)?



IMPORTANT: The restore defaults feature does not securely erase any data on your hard drive. See question and answer 6 for steps to securely erase data.

The restore defaults feature does not reset the Custom Secure Boot keys. See question and answer 7 for information about resetting the keys.

- a. Turn on or restart the computer, and then quickly press **esc**.
- b. Select **Main**, and then select **Apply Factory Defaults and Exit**.

- c. Follow the on-screen instructions.
- d. Select **Main**, select **Save Changes and Exit**, and then follow the on-screen instructions.

2. What is a UEFI BIOS, and how is it different from a legacy BIOS?

The Unified Extensible Firmware Interface (UEFI) BIOS is an industry-standard software interface between the platform firmware and an operating system (OS). It replaces the older BIOS architecture but supports much of the legacy BIOS functionality.

Like the legacy BIOS, the UEFI BIOS provides an interface to display the system information and configuration settings and to change the configuration of your computer before an OS is loaded. BIOS provides a secure runtime environment that supports a Graphic User Interface (GUI). In this environment, you can use either a pointing device (touch screen, touchpad, pointing stick, or USB mouse) or the keyboard to navigate and make menu and configuration selections. The UEFI BIOS also contains basic system diagnostics.

The UEFI BIOS provides functionality beyond that of the legacy BIOS. In addition, the UEFI BIOS works to initialize the computer's hardware before loading and executing the OS; the runtime environment allows the loading and execution of software programs from storage devices to provide more functionality, such as advanced hardware diagnostics (with the ability to display more detailed system information) and advanced firmware management and recovery software.

HP has provided options in Computer Setup (BIOS) to allow you to run in legacy BIOS, if required by the operating system. Examples of this requirement would be if you upgrade or downgrade the OS.

3. Where is the UEFI BIOS located?

The UEFI BIOS is located on a flash memory chip. You must use a utility to write to the chip.

4. What kind of configuration data is stored on the DIMM Serial Presence Detect (SPD) memory module? How would this data be written?

The DIMM SPD memory contains information about the memory module, such as size, serial number, data width, speed and timing, voltage, and thermal information. This information is written by the module manufacturer and stored on an EEPROM. You cannot write to this EEPROM when the memory module is installed in a computer. Third-party tools do exist that can write to the EEPROM when the memory module is not installed in a computer. Various third-party tools are available to read SPD memory.

5. What is meant by "Restore the nonvolatile memory found in Intel-based system boards"?

This message relates to clearing the Real Time Clock (RTC) CMOS memory that contains computer configuration data.

6. How can the BIOS security be reset to factory defaults and erase the data?

 **IMPORTANT:** Resetting results in the loss of information.

These steps do not reset Custom Secure Boot Keys. See question and answer 7 for information about resetting the keys.

- a. Turn on or restart the computer, and then quickly press **esc**.
- b. Select **Main**, and then select **Reset Security to Factory Defaults**.

- c. Follow the on-screen instructions.
 - d. Select **Main**, select **Save Changes and Exit**, and then follow the on-screen instructions.
7. **How can the Custom Secure Boot Keys be reset?**
- Secure Boot is a feature to ensure that only authenticated code can start on a platform. If you enabled Secure Boot and created Custom Secure Boot Keys, disabling Secure Boot does not clear the keys. You must also select to clear the Custom Secure Boot Keys. Use the same Secure Boot access procedure that you used to create the Custom Secure Boot Keys, but select to clear or delete all Secure Boot Keys.
- a. Turn on or restart the computer, and then quickly press **esc**.
 - b. Select the **Security** menu, select **Secure Boot Configuration**, and then follow the on-screen instructions.
 - c. At the **Secure Boot Configuration** window, select **Secure Boot**, select **Clear Secure Boot Keys**, and then follow the on-screen instructions to continue.

Using HP Sure Start (select products only)

Select computer models are configured with HP Sure Start, a technology that continuously monitors your computer's BIOS for attacks or corruption.

If the BIOS becomes corrupted or is attacked, HP Sure Start restores the BIOS to its previously safe state, without user intervention. Those select computer models ship with HP Sure Start configured and enabled. HP Sure Start is configured and already enabled so that most users can use the HP Sure Start default configuration. Advanced users can customize the default configuration.

To access the latest documentation on HP Sure Start, go to <http://www.hp.com/support>.

12 Power cord set requirements

The power supplies on some computers have external power switches.

The voltage select switch feature on the computer permits it to operate from any line voltage of 100 V ac–120 V ac or 220 V ac–240 V ac. Power supplies on those computers that do not have external power switches are equipped with internal switches that sense the incoming voltage and automatically switch to the proper voltage.

The power cord set received with the computer meets the requirements for use in the country where you purchased the equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer.

General requirements

These requirements are applicable to all countries.

1. The power cord must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be installed.
2. The power cord set must have a minimum current capacity of 10A (7A Japan only) and a nominal voltage rating of 125 V ac or 250 V ac, as required by each country's power system.
3. The diameter of the wire must be a minimum of 0.75 mm² or 18AWG, and the length of the cord must be between 1.8 m (6 ft) and 3.6 m (12 ft).

The power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.

 **WARNING!** Do not operate this product with a damaged power cord set. If the power cord set is damaged in any manner, replace it immediately.

Japanese power cord requirements

For use in Japan, use only the power cord received with this product.

 **IMPORTANT:** Do not use the power cord received with this product on any other products.

Country-specific requirements

This information provides additional requirements specific to a country.

Table 12-1 Power cord country-specific requirements

| Country | Accrediting Agency | Country | Accrediting Agency |
|---------------|--------------------|--------------------|--------------------|
| Australia (1) | EANSW | Italy (1) | IMQ |
| Austria (1) | OVE | Japan (3) | METI |
| Belgium (1) | CEBC | Norway (1) | NEMKO |
| Canada (2) | CSA | Sweden (1) | SEMKO |
| Denmark (1) | DEMKO | Switzerland (1) | SEV |
| Finland (1) | SETI | United Kingdom (1) | BSI |
| France (1) | UTE | United States (2) | UL |
| Germany (1) | VDE | | |

1. The flexible cord must be Type H05VV-F, 3-conductor, 0.75mm² conductor size. Power cord set fittings (appliance coupler and plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. The flexible cord must be Type SVT or equivalent, No. 18 AWG, 3 conductor. The plug must be a 2-pole grounding type with a NEMA 5-15P (15 A, 125 V) or NEMA 6-15P (15 A, 250 V) configuration.
3. Appliance coupler, flexible cord, and plug must bear a T mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 0.75 mm² conductor size. Plug must be a 2-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V) configuration.

13 Specifications

This section provides specifications for your computer.

Table 13-1 Specifications

| | Metric | U.S. |
|--|---------------------|----------------|
| Dimensions | | |
| Width | 270 mm | 10.6 in |
| Depth | 303 mm | 11.9 in |
| Height | 95 mm | 3.7 in |
| Approximate weight | 3.9 kg | 8.6 lb |
| Temperature range | | |
| Operating | 5° to 35°C | 41° to 95°F |
| Nonoperating | -30° to 60°C | -22°F to 140°F |
| NOTE: Operating temperature is derated 1.0°C per 300 m (1000 ft) to 3000 m (10,000 ft) above sea level; no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit might be limited by the type and number of options installed. | | |
| Maximum altitude (unpressurized) | | |
| Operating | 5,000 m | 16,404 ft |
| Nonoperating | 15,240 m | 50,000 ft |
| Relative humidity (noncondensing) | | |
| Operating | 5% to 90% | |
| Nonoperating (38.7°C max wet bulb) | 5% to 90% | |
| Power supply | | |
| Operating voltage range | 90 Vac to 264 Vac | |
| Rated voltage range ¹ | 100 Vac to 240 Vac | |
| Rated line frequency | 50 Hz to 60 Hz | |
| Operating line frequency | 47 Hz to 63 Hz | |
| Standard efficiency | 65 W, 87% efficient | |

¹ This system uses an active power factor-corrected power supply. This allows the system to pass the CE mark requirements for use in the countries of the European Union. The active power factor-corrected power supply also has the added benefit of not requiring an input-voltage range select switch.

Index

A

- access panel
 - illustrated 5
 - locked 51
 - removal and replacement 21
- Advanced menu, Computer Setup 83
- audible codes 95
- audio problems 59

B

- backup, creating 109
- backups 109, 110
- battery
 - disposal 11, 18, 19
- battery replacement 43
- beep codes 95
- blinking lights 95
- boot order, changing 112
- booting options
 - Full Boot 91
 - Quick Boot 91

C

- cable management 11, 19, 20
- cable pinouts, SATA data 11, 19
- cables 9
- changing a Power-On password 99
- changing a Setup password 99
- cleaning
 - computer 11, 16
 - mouse 11, 16, 17
 - safety precautions 11, 16
- CMOS
 - clearing and resetting 99
- components
 - front panel 1
 - rear panel 2
- computer cleaning 11, 16

Computer Setup

- access problem 51
 - Advanced menu 83
 - Main menu 76
 - Security menu 79
- Computer Setup Utility 75
- country power cord set requirements 121
- Customer Support 49

D

- deleting a Power-On password 100
- deleting a Setup password 100
- drive cage
 - removal and replacement 29

E

- electrostatic discharge (ESD) 11, 12
 - preventing damage 11, 12, 13
- error
 - codes 91, 95
- error messages 91
- expansion card
 - illustrated 5
 - removal 28

F

- F10 Setup 75
 - access problem 51
- fan shroud
 - illustrated 5
 - removal and replacement 38
- flash drive problems 71
- front bezel
 - illustrated 5
 - removal and replacement 23
- front panel components 1

G

- general problems 51
- grounding methods 11, 12, 13

H

- hard drive
 - illustrated 5
 - installation 30
 - proper handling 11, 18
 - removal 30
 - SATA characteristics 11, 19
 - hard drive problems 57
 - hard drives 8
 - hardware installation problems 64
 - heat sink
 - removal and replacement 39
 - heat sink with fan
 - illustrated 5
 - helpful hints 50
 - hood sensor
 - illustrated 5
 - hood sensor module
 - removal and replacement 24
 - HP PC Hardware Diagnostics UEFI
 - downloading 106
 - starting 105
 - using 105
 - HP PC Hardware Diagnostics Windows
 - accessing 103
 - downloading 104
 - installing 104
 - using 102
 - HP Recovery media
 - recovery 111
 - HP Sure Recover 112
 - HP Sure Start 113, 119
- ## I
- illustrated parts catalog 5

- installing
 - battery 43
 - hard drive 30
 - memory 25
 - optical drive 22
- internet access problems 72
- K**
- keyboard
 - cleaning 11, 16
 - keyboard problems 63
- L**
- lights
 - blinking PS/2 keyboard 95
- M**
- Main menu, Computer Setup 76
- mass storage devices 8
- memory
 - installation 25
 - nonvolatile 113
 - problems 69
 - socket population 25
 - volatile 113
- memory module
 - illustrated 5
- miscellaneous parts 10
- mouse
 - cleaning 11, 16, 17
 - problems 63
- N**
- network problems 66
- nonvolatile memory 113
- numeric error codes 91
- O**
- operating guidelines 11, 14
- optical disc drive
 - illustrated 5
- optical drive
 - installation 22
 - removal 22
- optical drives 8
- overheating, prevention 11, 14
- P**
- password
 - Power-On 99, 100
 - security 99
 - Setup 99, 100
- POST error messages 91
- power cord set requirements
 - country specific 121
- power problems 55
- power supply
 - illustrated 5
 - operating voltage range 123
 - removal and replacement 42
- Power-On password 99, 100
- printer problems 61
- problems
 - audio 59
 - Computer Setup 51
 - F10 Setup 51
 - flash drive 71
 - general 51
 - hard drive 57
 - hardware installation 64
 - internet access 72
 - keyboard 63
 - memory 69
 - mouse 63
 - network 66
 - power 55
 - printer 61
 - software 73
- processor
 - illustrated 5
 - removal and replacement 40
- product features 1
- product ID locations 3
- R**
- rear panel components 2
- recovery 109, 111
 - discs 111
 - media 111
 - USB flash drive 111
- recovery media 110
 - creating using HP Cloud Recovery Download Tool 110
 - creating using Windows tools 110
- Remote HP PC Hardware Diagnostics
 - UEFI settings
 - customizing 108
 - using 107
- removal and replacement
 - drive cage 29
 - fan shroud 38
 - front bezel 21, 23
 - heat sink 39
 - hood sensor module 24
 - power supply 42
 - processor 40
 - solid-state drive 37
 - speaker 34
 - system board 46
 - WLAN module 35
- removing
 - battery 43
 - expansion card 28
 - hard drive 30
 - optical drive 22
- removing personal data from volatile system memory 113
- restoring 109
- S**
- safety precautions
 - cleaning 11, 16
- SATA
 - connectors on system board 11, 19
 - data cable pinouts 11, 19
 - hard drive characteristics 11, 19
- screws, correct size 11, 18
- Security menu, Computer Setup 79
- serial number locations 3
- service considerations 11, 18
- Setup password 99, 100
- software
 - problems 73
 - servicing computer 11, 18
- solid-state drive
 - illustrated 5
- solid-state drive module
 - removal and replacement 37
- solid-state drives 8
- speaker
 - illustrated 5
 - removal and replacement 34
- specifications
 - computer 123
- standard configuration 1
- static electricity 11, 12

- system board
 - illustrated 5
 - removal and replacement 46
 - SATA connectors 11, 19
- system chassis
 - illustrated 5
- system memory, removing personal data from volatile 113
- system restore 111
- system restore point, creating 110

T

- temperature control 11, 14
- tools, servicing 11, 18
- Torx T15 screwdriver 11, 18
- troubleshooting without diagnostics 49

U

- using Computer Setup Utilities 75

V

- ventilation, proper 11, 14

W

- Windows
 - backup 109
 - recovery media 109
 - system restore point 110
- Windows tools, using 110
- WLAN module
 - illustrated 5
 - removal and replacement 35

